

# DST Setting/Module :3208

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, press **C** several times.



In the Timekeeping Mode, press **B**.



Seconds will flash.



Press **C**. Hours blinks, so enter the hour(ten) you want to change.

4.



Press ⓐ again. Hours blinks, so enter the hour(one) you want to change.

5.



Press ⓑ to return to the Timekeeping Mode.

<Timekeeping Mode Screen>

