



# READ THIS!

## Safety Precautions

Thank you for selecting this CASIO product.
• Before using the instrument, be sure to carefully read through the instructions contained in this leaflet.
• Please keep all information for future reference.

- ⚠ DANGER Indicates something that creates a major risk of death or serious personal injury.
⚠ WARNING Indicates something that creates a risk of death or serious personal injury.
⚠ CAUTION Indicates something that creates a risk of minor personal injury or physical damage.

Symbol Examples
This triangle symbol (⚠) means that the user should be careful.
This circle with a line through it (⊘) means that the indicated action must not be performed.
The black dot (●) means that the indicated action must be performed.

## ⚠ DANGER

### Battery Precautions

- Do not allow a battery to come into contact with fresh water, salt water, or other moisture.
Observe the precautions below in order to avoid battery overheating, fire, and rupture.
Do not expose a battery to fire or heat.
Do not carry or store a battery together with necklaces, coins, or other metal objects.
Do not try to disassemble or modify a battery.
Do not peel the external decorative sticker from a battery.
Always use only the specified type of battery.

### Immediately after noticing any fluid leak, abnormal odor, overheating, discoloration, deformation or other battery abnormality, very carefully remove the battery from the product and/or charger. Keep the removed battery away from fire. Do not use a battery exhibiting any abnormality.

### Do not use or leave a battery in a location exposed to direct sunlight, in an automobile parked outside, near open flame, a stove, or in any location subjected to high heat.

### Should fluid from a battery get on your skin or clothing, immediately rinse it off with clean water.

### Use only the specified charger to charge the rechargeable nickel metal hydride batteries.

### Do not use rechargeable nickel metal hydride batteries that do not finish charging even if charged for longer than the normal specified time.

### Use a set of fully charged nickel-metal hydride batteries. Make sure that each of the batteries in a set is fully charged as soon as possible before after the other batteries are charged.

### When leaving the product unattended, unplug the AC adaptor and put the product in a place that is away from animals and pets.

### In the case of a lightning storm, do not touch the device plugged into the power outlet.

## ⚠ WARNING

### Storage and Operation Locations

- Do not store or use the product in any of the locations described below.
Areas subjected to large amounts of moisture and dust
Food preparation areas, near a humidifier, or in areas where the product is exposed to oil smoke or water vapor
Near a heating device, on an electric carpet, in a location exposed to direct sunlight, in a car parked outside, or any other area where the product is subjected to high temperatures.

### Do not locate the product on an unstable platform, on an uneven surface, or in any other unstable location. Take care to avoid locations such as folded carpeting, on top of the power cord, etc. Be sure to secure the stand to the product.

### Do not place heavy objects on the product.

### Do not climb up on the product and stand. (Stand is available as an option.)

### Do not do not climb up on the product or rock it back and forth. Particular care is required in areas where young children are present.

### Abnormalities (Smoke, Odor, Heat Generation, etc.)

### Do not use the product if it is emitting smoke, odor, heat, or exhibiting any other abnormality. Do not use the product after it has been dropped or otherwise damaged.

### Should the LCD become cracked, never touch any of the LCD inside.

### Disassembly and Modification

### Do not attempt any disassembly or modification. For any internal inspection, adjustment, or repair, contact your original retailer or a CASIO Service Center.

### Suffocation and Choking Risks

### Do not allow anyone to play with the plastic bags used for product packaging.

### Avoiding Water and Foreign Matter

### Do not allow water, other liquids (sports drinks, seawater, animal or pet urine, etc.), or foreign objects (metal fragments, etc.) to get into the product or the AC adaptor. Should any such matter get into the product, immediately perform the steps below.

### Do not locate any of the items listed below on top of or next to the product, AC adaptor, or keyboard cover.

### Correct Stand Assembly (Stand is available as an option.)

### This Product

### AC Adaptor and Power Cord

### When moving this product, make sure to use both hands to pick it up.

### Strap Lock (Guitar Strap Compatible Models Only)

### When handling the strap lock, take care to avoid swallowing by small children. Store it in a place away from small children.

### After attaching a guitar strap, check the strap lock to make sure that it is securely attached from above. Do not use a damaged strap lock.

### Commercially Available Guitar Strap (Guitar Strap Compatible Models Only)

### Do not pick up the product, transport it, or swing it around by the commercially available guitar strap.

## ⚠ WARNING

### Medical devices affected by electromagnetism

- Keep this product away from the chest area of any individual fitted with a cardiac pacemaker.
Cardiac pacemakers and similar devices can be affected by electromagnetism.
Wipe the product with a soft, dry cloth. Do not use a tissue, which can cause scratching.

## ⚠ CAUTION

### Battery Precautions

### Observe the precautions below. Failure to do so can cause a battery to rupture, creating the risk of fire, personal injury, and soiling of nearby objects by leaking fluid.

### Do not use a leaking battery.

### Keep batteries away from children. During use, make sure that small children are unable to remove batteries from the product.

### Do not leave a battery near areas used by pets.

### AC Adaptor and Power Cord

### Do not prevent fire and electric shock from the AC adaptor and power cord, be sure to observe the precautions below.

### Do not insert foreign objects (pieces of metal, pencils, etc.) into connections.

### User Maintenance

### Connections

### Volume Level

### Backing Up Important Data

### Correct Stand Assembly (Stand is available as an option.)

### Stand Safety Precautions (Stand is available as an option.)

### Health Precautions (Lighting Keyboard models only)

### Bench (Available as an option.)

### This Product

## Operating Precautions

- Environment
To prevent the formation of mold, set up the product in a well-ventilated location where the temperature and humidity ranges shown below are maintained.
Sterilization and Disinfection
Wipe the product with a soft, dry cloth. Do not use a tissue, which can cause scratching.

### Included and Optional Accessories

### Weld Lines

### AC Adaptor Handling Precautions

### Batteries

### Do not use a battery near areas used by pets.

### Do not prevent fire and electric shock from the AC adaptor and power cord, be sure to observe the precautions below.

### Do not insert foreign objects (pieces of metal, pencils, etc.) into connections.

### User Maintenance

### Connections

### Volume Level

### Backing Up Important Data

### Correct Stand Assembly (Stand is available as an option.)

### Stand Safety Precautions (Stand is available as an option.)

### Health Precautions (Lighting Keyboard models only)

### Bench (Available as an option.)

### This Product

## ¡LEA ESTO!

## Precauciones de seguridad

Gracias por seleccionar este producto CASIO.
• Antes de utilizar el instrumento, asegúrese de leer atentamente las instrucciones indicadas en este folleto.
• Por favor guarde toda la información para futuras consultas.

- ⚠ PELIGRO Indica una situación que implica riesgo inminente de muerte o lesiones graves.
⚠ ADVERTENCIA Indica una situación que implica riesgo de muerte o lesiones graves.
⚠ PRECAUCIÓN Indica una situación que implica riesgo de lesiones o daños materiales menores.

### Ejemplos de símbolos

### ⚠ PELIGRO

### ⚠ ADVERTENCIA

### ⚠ PRECAUCIÓN

### Precauciones con las pilas

### No deje que la batería entre en contacto con agua dulce, agua salada u otras fuentes de humedad. No utilice una batería mojada.

### Observe las siguientes precauciones para evitar el sobrecalentamiento, incendio y rotura de la batería.

### No intente desarmar ni modificar.

### Para cargar las pilas de níquel-metal hidruo recargables utilice solo el cargador especificado.

### No utilice pilas de níquel-metal hidruo recargables si la carga no se completa, incluso si las ha cargado por más tiempo que el especificado.

### Evite el agua y las impurezas

### Nivel de volumen

### Respaldo de los datos importantes

### Montaje correcto del soporte (Soporte disponible como opción.)

### Este producto

### No arroje el producto al fuego.

### No deje caer el producto y evite que reciba impactos.

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

## ⚠ ADVERTENCIA

- En caso de tormenta eléctrica, no toque el dispositivo si está enchufado a la toma de corriente.
Los relámpagos implican el riesgo de descargas eléctricas.

### Lugares para el almacenamiento y funcionamiento

### No guarde ni utilice el producto en ninguno de los lugares que se describen a continuación.

### No coloque el producto sobre un tablero inestable, sobre una superficie irregular o en cualquier otro lugar inestable.

### No se suba al producto o soporte. (Soporte disponible como opción.)

### No se suba al producto ni lo balancee hacia atrás y hacia adelante. Se requiere especial atención en presencia de niños pequeños.

### Normalidades (generación de humo, olores, calor, etc.)

### Antormalidades (generación de humo, olores, calor, etc.)

### Desarmado y modificación

### Riesgos de asfixia y atragantamiento

### Evite el agua y las impurezas

### Nivel de volumen

### Respaldo de los datos importantes

### Montaje correcto del soporte (Soporte disponible como opción.)

### Este producto

### No arroje el producto al fuego.

### No deje caer el producto y evite que reciba impactos.

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

## ⚠ ADVERTENCIA

- Tras colocar la correa de guitarra, verifique el cierre de la correa para asegurarse de que se encuentra firmemente colocado desde arriba. No utilice un cierre de correa dañado.
Una mala o no colocación del cierre de la correa podría hacer que la correa de guitarra se desprenda, con el consiguiente riesgo de caída del producto, que causaría a su vez daños en el producto y lesiones personales.

### Correa de guitarra disponible comercialmente (Solo modelos compatibles con correa de guitarra)

### Dispositivos médicos afectados por el electromagnetismo

### Mantenga este producto alejado del área del pecho de cualquier persona que lleve un marcapasos.

### Precauciones con las pilas

### Observe las baterías fuera del alcance de los niños. Durante el uso, asegúrese de que los niños no puedan retirar las pilas del producto.

### Mantenga las baterías fuera del alcance de las mascotas.

### Adaptador de CA y cable de alimentación

### Mantenimiento por el usuario

### Antes de limpiar el producto, apáguelo y desenchúfelo el adaptador de CA de la toma de corriente.

### Conexiones

### Nivel de volumen

### Respaldo de los datos importantes

### Montaje correcto del soporte (Soporte disponible como opción.)

### Este producto

### No arroje el producto al fuego.

### No deje caer el producto y evite que reciba impactos.

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

## ⚠ PRECAUCIÓN

- Se ha informado que, en casos muy raros, la exposición a una luz intensa o una luz intermitente puede causar espasmos musculares momentáneos, pérdida de conciencia u otros síntomas.
• Toda persona que haya experimentado estos síntomas deberá consultar con un médico antes de usar este producto.
• Utilice este producto en un lugar bien iluminado.

### Banqueta (Disponible como opción.)

### Este producto

### Precauciones operacionales

### Entorno

### Mantenimiento por el usuario

### Accesorios incluidos y opcionales

### Lineas de soldadura

### Precauciones sobre el manejo del adaptador de CA

### Pilas

### Conexiones

### Nivel de volumen

### Respaldo de los datos importantes

### Montaje correcto del soporte (Soporte disponible como opción.)

### Este producto

### No arroje el producto al fuego.

### No deje caer el producto y evite que reciba impactos.

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto

### Este producto



