



English

READ THIS!

Safety Precautions

Thank you for selecting this CASIO product.

- Before using the instrument, be sure to carefully read through the Safety Precautions contained in this leaflet and the Operating Precautions provided on the CASIO website to ensure that you use the instrument correctly in accordance with the User's Guide.
- Please keep all information for future reference.

⚠ DANGER	Indicates something that creates a major risk of death or serious personal injury.
⚠ WARNING	Indicates something that creates a risk of death or serious personal injury.
⚠ CAUTION	Indicates something that creates a risk of minor personal injury or physical damage.

Symbol Examples

⚠ This triangle symbol (⚠) means that the user should be careful. (The example at left indicates electrical shock caution.)

⊘ This circle with a line through it (⊘) means that the indicated action must not be performed. Indications within or nearby this symbol are specifically prohibited. (The example at left indicates that disassembly is prohibited.)

● The black dot (●) means that the indicated action must be performed. Indications within this symbol are actions that are specifically instructed to be performed. (The example at left indicates that the power plug must be unplugged from the electrical socket.)

- ⚠** If this product is used by a child or in the presence of children, always take care to ensure that adequate adult supervision is provided.
- ⚠** Do not use the stand, soft case, bench or pedals for anything other than the specified purpose.

⚠ DANGER	
Battery Precautions	
<ul style="list-style-type: none"> Do not allow a battery to come into contact with fresh water, salt water, or other moisture. Do not use a battery that is wet. Doing so creates the risk of battery overheating, fire, and rupture. Observe the precautions below in order to avoid battery overheating, fire, and rupture. <ul style="list-style-type: none"> Do not expose a battery to fire or heat. Load a battery with its poles (plus (+) and minus (-)) facing correctly. Do not carry or store a battery together with necklaces, coins, or other metal objects. Do not try to disassemble or modify a battery, pierce it with a needle, subject it to strong impact (by stepping on it etc.), or apply solder directly to it. Do not peel the external decorative sticker from a battery. Do not put a battery into a microwave oven, dryer, high-pressure vessel, etc. Always use only the specified type of battery. Immediately after noticing any fluid leak, abnormal odor, overheating, discoloration, deformation or other battery abnormality, very carefully remove the battery from the product and/or charger. Keep the removed battery away from fire. Do not use a battery exhibiting any abnormality. 	
Continued use creates the risk of battery overheating, fire, and rupture.	
<ul style="list-style-type: none"> Do not use or leave a battery in a location exposed to direct sunlight, in an automobile parked outside, near open flame, a stove, or in any location subjected to high heat. 	
Such conditions create the risk of battery overheating, fire, and rupture.	
<ul style="list-style-type: none"> Should fluid from a battery get on your skin or clothing, immediately rinse it off with clean water. 	
Fluid creates the risk of skin irritation. Battery fluid getting into the eyes creates the risk of eyesight loss, etc.	
<ul style="list-style-type: none"> Use only the specified charger to charge the rechargeable nickel metal hydride batteries. 	
Using a non-specified charger creates the risk of abnormal charging, overheating, fire, and explosion.	
<ul style="list-style-type: none"> Do not use rechargeable nickel metal hydride batteries that do not finish charging even if charged for longer than the normal specified time. 	
This could indicate that the batteries have deteriorated and cannot perform as expected, which creates the risk of overheating, fire, and explosion.	
<ul style="list-style-type: none"> Use nickel metal hydride batteries that have been charged to full capacity at the same time. 	
Using batteries with different levels of charge can cause premature deterioration and creates the risk of overheating, fire, and explosion.	

⚠ WARNING	
AC Adaptor and Power Cord	
<ul style="list-style-type: none"> To prevent fire and electric shock from the AC adaptor and power cord, be sure to observe the precautions below. <ul style="list-style-type: none"> Use only the specified type of AC adaptor. Use only the included power cord. Use the AC adaptor only with the device specified for it. Use the included power cord with this product only. Do not plug the power cord into an outlet with the wrong voltage rating. Do not plug into an overloaded extension cord or power outlet. Do not cover the power cord with a blanket or other material during use, and keep it away from heating devices. Do not place heavy objects on the power cord and do not leave it bundled during use. Do not subject a power cord to heat or attempt to modify it, and avoid damaging it. Do not subject the power cord to excessive bending, twisting, or pulling. Make sure the power cord is not pinched between the wall and the rack or table where the product is located, and never cover the power cord with a cushion or other object. Should the AC adaptor or power cord become damaged, contact a CASIO Service Center. Do not touch the plug with wet hands. 	
<ul style="list-style-type: none"> When leaving the product unattended, unplug the AC adaptor and put the product in a place that is away from animals and pets. 	
Pets chewing on the AC adaptor or pet urine can cause shorting, which creates the risk of fire.	

⚠ WARNING	
<ul style="list-style-type: none"> In the case of a lightning storm, do not touch the device plugged into the power outlet. <ul style="list-style-type: none"> Lightning creates the risk of electric shock. 	
Storage and Operation Locations	
<ul style="list-style-type: none"> Do not store or use the product in any of the locations described below. <ul style="list-style-type: none"> Doing so creates the risk of fire and electric shock. Areas subjected to large amounts of moisture and dust Food preparation areas, near a humidifier, or in areas where the product is exposed to oil smoke or water vapor Near a heating device, on an electric carpet, in a location exposed to direct sunlight, in a car parked outside, or any other area where the product is subjected to high temperatures. Do not locate the product on an unsteady platform, on an uneven surface, or in any other unstable location. Take care to avoid locations such as folded carpeting, on top of the power cord, etc. Be sure to secure the stand to the product. 	
Secure the stand to the product as described in the user documentation.	
<ul style="list-style-type: none"> Do not place heavy objects on the product. Dropping and tipping over create the risk of personal injury. 	
Do not climb up on the product and stand. (Stand-compatible models only)	
<ul style="list-style-type: none"> Do not climb up on the product or rock it back and forth. Particular care is required in areas where young children are present. 	
Doing so can cause the stand to fall over, creating the risk of personal injury.	
Abnormalities (Smoke, Odor, Heat Generation, etc.)	
<ul style="list-style-type: none"> Do not use the product if it is emitting smoke, odor, heat, or exhibiting any other abnormality. Do not use the product after it has been dropped or otherwise damaged. 	
Doing so creates the risk of fire and electric shock. Immediately perform the steps below.	
<ol style="list-style-type: none"> Turn off power. If you are using an AC adaptor, unplug its power plug from the power outlet. Contact your original retailer or a CASIO Service Center. 	
Display Screen (Screen-equipped models only)	
<ul style="list-style-type: none"> Do not press the LCD or subject it to strong impact. 	
Doing so can cause the LCD glass to crack, creating the risk of personal injury.	
<ul style="list-style-type: none"> Should the LCD become cracked, never touch any of the liquid inside. 	
LCD liquid getting on the skin creates the risk of skin irritation. Should LCD liquid get into your mouth, immediately rinse your mouth out and contact your physician.	
Should LCD liquid get in your eyes or on your skin, rinse with clean water and then contact your physician.	
Disassembly and Modification	
<ul style="list-style-type: none"> Do not attempt any disassembly or modification. For any internal inspection, adjustment, or repair, contact your original retailer or a CASIO Service Center. 	
Doing so creates the risk of electric shock, burn injury, and personal injury.	
Suffocation and Choking Risks	
<ul style="list-style-type: none"> Do not allow anyone to play with the plastic bags used for product packaging. 	
Plastic bags create the risk of suffocation when placed over the head, when swallowed, etc. Particular care is required in areas where young children are present.	
Avoiding Water and Foreign Matter	
<ul style="list-style-type: none"> Do not allow water, other liquids (sports drinks, seawater, animal or pet urine, etc.), or foreign objects (metal fragments, etc.) to get into the product or the AC adaptor. Should any such matter get into the product, immediately perform the steps below. 	
Continued use creates the risk of fire and electric shock.	
<ol style="list-style-type: none"> Turn off power. If you are using an AC adaptor, unplug its power plug from the power outlet. Contact your original retailer or a CASIO Service Center. 	

⚠ WARNING	
Medical devices affected by electromagnetism	
<ul style="list-style-type: none"> Keep this product away from the chest area of any individual fitted with a cardiac pacemaker. 	
Cardiac pacemakers and similar devices can be affected by electromagnetism. Should anyone fitted with a cardiac pacemaker or other medical device ever experience any abnormality, move the product away and contact a physician.	
Small Components	
<ul style="list-style-type: none"> Handle small parts with care to ensure that they are not swallowed by small children. 	
If a part is accidentally swallowed, immediately consult a physician.	
This Product	
<ul style="list-style-type: none"> Do not insert your hand or fingers into gaps in the product. 	
Doing so creates the risk of personal injury, and malfunction of and damage to the product.	
<ul style="list-style-type: none"> When turning this product over or standing it on end, always disconnect all the plugs on the back of the product. 	
Striking the plugs against a table or the floor could damage the connectors.	
⚠ CAUTION	
Battery Precautions	
<ul style="list-style-type: none"> Observe the precautions below. Failure to do so can cause the battery to rupture, creating the risk of fire, personal injury, and soiling of nearby objects by leaking fluid. 	
<ul style="list-style-type: none"> Never allow a battery to become shorted. Do not mix old and new batteries. Do not mix different battery types. Do not charge a non-rechargeable battery. If you do not plan to use the product for a long time, remove batteries. Replace the batteries as soon as possible after they go dead. Do not use a battery whose cover has been peeled off. 	
<ul style="list-style-type: none"> Do not use a leaking battery. 	
Doing so creates the risk of fire and electric shock. Immediately stop using the product and contact your original retailer or a CASIO Service Center.	
<ul style="list-style-type: none"> Keep batteries away from children. During use, make sure that small children are unable to remove batteries from the product. 	
<ul style="list-style-type: none"> Do not leave a battery near areas used by pets. 	
Pets chewing on a battery creates the risk of fluid leaking, overheating, fire, and rupture.	
AC Adaptor and Power Cord	
<ul style="list-style-type: none"> To prevent fire and electric shock from the AC adaptor and power cord, be sure to observe the precautions below. <ul style="list-style-type: none"> Grasp the power plug when unplugging it from the wall outlet. Do not use detergent when cleaning the power cord, especially the power plug and jack parts. Insert the power plug into the outlet as far as it will go. If you do not plan to use the product for a long time, unplug from the power outlet. At least once a year, unplug the power plug from the power outlet and use a dry cloth to wipe away any dust buildup from the area between the prongs of the plug. Before moving the product, turn it off and unplug from the power outlet. 	
<ul style="list-style-type: none"> Do not use the product if it is emitting smoke, odor, heat, or exhibiting any other abnormality. Do not use the product after it has been dropped or otherwise damaged. 	
Doing so creates the risk of fire and electric shock. Immediately perform the steps below.	
<ol style="list-style-type: none"> Turn off power. If you are using an AC adaptor, unplug its power plug from the power outlet. Contact your original retailer or a CASIO Service Center. 	
Display Screen (Screen-equipped models only)	
<ul style="list-style-type: none"> Do not press the LCD or subject it to strong impact. 	
Doing so can cause the LCD glass to crack, creating the risk of personal injury.	
<ul style="list-style-type: none"> Should the LCD become cracked, never touch any of the liquid inside. 	
LCD liquid getting on the skin creates the risk of skin irritation. Should LCD liquid get into your mouth, immediately rinse your mouth out and contact your physician.	
Should LCD liquid get in your eyes or on your skin, rinse with clean water and then contact your physician.	
User Maintenance	
<ul style="list-style-type: none"> Before cleaning the product, turn off power and unplug the AC adaptor from the power outlet. 	
Failure to do so creates the risk of electric shock. Leaving the AC adaptor plugged in creates the risk of damage to the power cord, fire, and electric shock.	
Connections	
<ul style="list-style-type: none"> Connect only specified devices and items to connectors. Do not insert foreign objects (pieces of metal, pencils, etc.) into connections. 	
Connecting to other devices and items creates the risk of fire and electric shock.	
Volume Level	
<ul style="list-style-type: none"> Do not listen at very loud volumes for long periods. 	
High volume settings can damage hearing. Particular care is required concerning this precaution when using headphones.	
Backing Up Important Data	
<ul style="list-style-type: none"> Always keep backup copies of important data by transferring it to a computer or other storage device. 	
Note that data can be deleted in the case of product malfunction, repair, etc.	
Correct Stand Assembly (Stand-compatible models only)	
<ul style="list-style-type: none"> Be sure to observe the precautions below. <ul style="list-style-type: none"> Perform assembly as instructed in the user documentation. Make sure the instrument is correctly mounted on the stand. When placing the instrument on the stand, take care to avoid pinching your fingers between the stand. Two or more people should work together when mounting or moving the instrument. When mounting or moving the instrument, do not drag or tilt the stand. 	
Failure to do so can cause the stand to tip over and the instrument to fall, creating the risk of personal injury.	
Stand Safety Precautions (Stand-compatible models only)	
<ul style="list-style-type: none"> Should you notice any unsteadiness, missing screws, loose screws, or any other problems while playing, contact your original retailer or a CASIO Service Center. Periodically check for loose screws. Securely tighten loose screws. 	
Failure to do so can cause the stand to tip over and the instrument to fall, creating the risk of personal injury.	
Health Precautions (Lighting Keyboard models only)	
<ul style="list-style-type: none"> It has been reported that in very rare cases, exposure to strong light or flashing light can cause momentary muscle spasms, loss of consciousness, or other symptoms. 	
<ul style="list-style-type: none"> Individuals who have experienced such symptoms should consult with a physician before using this product. Use this product in a brightly lit location. Should anyone experience symptoms like the ones described here, immediately stop using the product and contact a physician. 	
Bench (Bench-compatible Models Only)	
<ul style="list-style-type: none"> Use the bench for its intended purpose only. 	
Using the bench as a plaything or step ladder can cause it to tip over, creating the risk of personal injury.	
<ul style="list-style-type: none"> Never allow more than one person to sit on the bench at one time. 	
Doing so can over exert stress the player's posture or cause the bench to tip over, creating the risk of personal injury.	
<ul style="list-style-type: none"> Never attempt to adjust the height of the piano bench while still sitting on it. 	
Doing so creates the risk of trapping your fingers between the frame and the seat.	
<ul style="list-style-type: none"> Periodically check for looseness in the nuts securing the bench seat to the frame. Use the wrench provided to firmly tighten any nuts that are loose. 	
Using the bench while the nuts are loose can cause the bench to tip over or break, creating the risk of personal injury.	
<ul style="list-style-type: none"> Spread felt or some other type of cloth under the bench to avoid direct contact between the rubber on its legs and the floor surface. 	
Direct contact between the rubber and flooring can cause discoloration, marring, or other damage.	

⚠ WARNING	
Medical devices affected by electromagnetism	
<ul style="list-style-type: none"> Keep this product away from the chest area of any individual fitted with a cardiac pacemaker. 	
Cardiac pacemakers and similar devices can be affected by electromagnetism. Should anyone fitted with a cardiac pacemaker or other medical device ever experience any abnormality, move the product away and contact a physician.	
Small Components	
<ul style="list-style-type: none"> Handle small parts with care to ensure that they are not swallowed by small children. 	
If a part is accidentally swallowed, immediately consult a physician.	
This Product	
<ul style="list-style-type: none"> Do not insert your hand or fingers into gaps in the product. 	
Doing so creates the risk of personal injury, and malfunction of and damage to the product.	
<ul style="list-style-type: none"> When turning this product over or standing it on end, always disconnect all the plugs on the back of the product. 	
Striking the plugs against a table or the floor could damage the connectors.	
⚠ CAUTION	
Battery Precautions	
<ul style="list-style-type: none"> Observe the precautions below. Failure to do so can cause the battery to rupture, creating the risk of fire, personal injury, and soiling of nearby objects by leaking fluid. 	
<ul style="list-style-type: none"> Never allow a battery to become shorted. Do not mix old and new batteries. Do not mix different battery types. Do not charge a non-rechargeable battery. If you do not plan to use the product for a long time, remove batteries. Replace the batteries as soon as possible after they go dead. Do not use a battery whose cover has been peeled off. 	
<ul style="list-style-type: none"> Do not use a leaking battery. 	
Doing so creates the risk of fire and electric shock. Immediately stop using the product and contact your original retailer or a CASIO Service Center.	
<ul style="list-style-type: none"> Keep batteries away from children. During use, make sure that small children are unable to remove batteries from the product. 	
<ul style="list-style-type: none"> Do not leave a battery near areas used by pets. 	
Pets chewing on a battery creates the risk of fluid leaking, overheating, fire, and rupture.	
AC Adaptor and Power Cord	
<ul style="list-style-type: none"> To prevent fire and electric shock from the AC adaptor and power cord, be sure to observe the precautions below. <ul style="list-style-type: none"> Grasp the power plug when unplugging it from the wall outlet. Do not use detergent when cleaning the power cord, especially the power plug and jack parts. Insert the power plug into the outlet as far as it will go. If you do not plan to use the product for a long time, unplug from the power outlet. At least once a year, unplug the power plug from the power outlet and use a dry cloth to wipe away any dust buildup from the area between the prongs of the plug. Before moving the product, turn it off and unplug from the power outlet. 	
<ul style="list-style-type: none"> Do not use the product if it is emitting smoke, odor, heat, or exhibiting any other abnormality. Do not use the product after it has been dropped or otherwise damaged. 	
Doing so creates the risk of fire and electric shock. Immediately perform the steps below.	
<ol style="list-style-type: none"> Turn off power. If you are using an AC adaptor, unplug its power plug from the power outlet. Contact your original retailer or a CASIO Service Center. 	
Display Screen (Screen-equipped models only)	
<ul style="list-style-type: none"> Do not press the LCD or subject it to strong impact. 	
Doing so can cause the LCD glass to crack, creating the risk of personal injury.	
<ul style="list-style-type: none"> Should the LCD become cracked, never touch any of the liquid inside. 	
LCD liquid getting on the skin creates the risk of skin irritation. Should LCD liquid get into your mouth, immediately rinse your mouth out and contact your physician.	
Should LCD liquid get in your eyes or on your skin, rinse with clean water and then contact your physician.	
User Maintenance	
<ul style="list-style-type: none"> Before cleaning the product, turn off power and unplug the AC adaptor from the power outlet. 	
Failure to do so creates the risk of electric shock. Leaving the AC adaptor plugged in creates the risk of damage to the power cord, fire, and electric shock.	
Connections	
<ul style="list-style-type: none"> Connect only specified devices and items to connectors. Do not insert foreign objects (pieces of metal, pencils, etc.) into connections. 	
Connecting to other devices and items creates the risk of fire and electric shock.	
Volume Level	
<ul style="list-style-type: none"> Do not listen at very loud volumes for long periods. 	
High volume settings can damage hearing. Particular care is required concerning this precaution when using headphones.	
Backing Up Important Data	
<ul style="list-style-type: none"> Always keep backup copies of important data by transferring it to a computer or other storage device. 	
Note that data can be deleted in the case of product malfunction, repair, etc.	
Correct Stand Assembly (Stand-compatible models only)	
<ul style="list-style-type: none"> Be sure to observe the precautions below. <ul style="list-style-type: none"> Perform assembly as instructed in the user documentation. Make sure the instrument is correctly mounted on the stand. When placing the instrument on the stand, take care to avoid pinching your fingers between the stand. Two or more people should work together when mounting or moving the instrument. When mounting or moving the instrument, do not drag or tilt the stand. 	
Failure to do so can cause the stand to tip over and the instrument to fall, creating the risk of personal injury.	
Stand Safety Precautions (Stand-compatible models only)	
<ul style="list-style-type: none"> Should you notice any unsteadiness, missing screws, loose screws, or any other problems while playing, contact your original retailer or a CASIO Service Center. Periodically check for loose screws. Securely tighten loose screws. 	
Failure to do so can cause the stand to tip over and the instrument to fall, creating the risk of personal injury.	
Health Precautions (Lighting Keyboard models only)	
<ul style="list-style-type: none"> It has been reported that in very rare cases, exposure to strong light or flashing light can cause momentary muscle spasms, loss of consciousness, or other symptoms. 	
<ul style="list-style-type: none"> Individuals who have experienced such symptoms should consult with a physician before using this product. Use this product in a brightly lit location. Should anyone experience symptoms like the ones described here, immediately stop using the product and contact a physician. 	
Bench (Bench-compatible Models Only)	
<ul style="list-style-type: none"> Use the bench for its intended purpose only. 	
Using the bench as a plaything or step ladder can cause it to tip over, creating the risk of personal injury.	
<ul style="list-style-type: none"> Never allow more than one person to sit on the bench at one time. 	
Doing so can over exert stress the player's posture or cause the bench to tip over, creating the risk of personal injury.	
<ul style="list-style-type: none"> Never attempt to adjust the height of the piano bench while still sitting on it. 	
Doing so creates the risk of trapping your fingers between the frame and the seat.	
<ul style="list-style-type: none"> Periodically check for looseness in the nuts securing the bench seat to the frame. Use the wrench provided to firmly tighten any nuts that are loose. 	
Using the bench while the nuts are loose can cause the bench to tip over or break, creating the risk of personal injury.	
<ul style="list-style-type: none"> Spread felt or some other type of cloth under the bench to avoid direct contact between the rubber on its legs and the floor surface. 	
Direct contact between the rubber and flooring can cause discoloration, marring, or other damage.	

⚠ CAUTION	
Soft Case (Soft-Case-Compatible Models Only)	
<ul style="list-style-type: none"> When relocating the product, always ensure that the fastener is closed beforehand. 	
Failing to do so could result in the product falling and causing damage or injury.	
Small Components	
<ul style="list-style-type: none"> Handle small parts with care to ensure that they are not swallowed by small children. 	
If a part is accidentally swallowed, immediately consult a physician.	
This Product	
<ul style="list-style-type: none"> Do not insert your hand or fingers into gaps in the product. 	
Doing so creates the risk of personal injury, and malfunction of and damage to the product.	
<ul style="list-style-type: none"> When turning this product over or standing it on end, always disconnect all the plugs on the back of the product. 	
Striking the plugs against a table or the floor could damage the connectors.	
⚠ CAUTION	
Battery Precautions	
<ul style="list-style-type: none"> Observe the precautions below. Failure to do so can cause the battery to explode or leak flammable liquid or gas. 	
<ul style="list-style-type: none"> Use only the type of battery that is specified for this product. Do not burn a battery or dispose of it in an incinerator, or by mechanical crushing or cutting. Do not subject a battery to excessively high or low temperatures during use, storage, or transport. Do not subject a battery to excessively low barometric pressure during use, storage, or transport. Allow the battery to cool down before replacing it. Failure to do so could result in a burn or other injury. 	
Registered Trademarks and Trademarks	
The terms below are registered trademarks or trademarks of their respective owners.	
Copyrights	
You are allowed to use recordings for your own personal use. Any reproduction of an audio or music format file, without the permission of its copyright holder, is strictly prohibited under copyright laws and international treaties. Also, making such files available on the Internet or distributing them to third parties, regardless of whether such activities are conducted with or without compensation, is strictly prohibited under copyright laws and international treaties. CASIO COMPUTER CO., LTD. shall not be held in any way liable for any use of this Digital Keyboard that is illegal under copyright laws.	
Company and product names used in this manual may be registered trademarks of others.	
NOTICE	
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. 	
FCC CAUTION	
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	
Manufacturer: CASIO COMPUTER CO., LTD. 6-2, Hon-machi 1-chome, Shibuya-ku, Tokyo 151-8543, Japan Responsible within the European Union: Casio Europe GmbH Casio-Platz 1, 22848 Norderstedt, Germany www.casio-europe.com	
UK CA This recycle mark indicates that the packaging conforms to the environmental protection legislation in Germany.	
Manufacturer: CASIO COMPUTER CO., LTD. 6-2, Hon-machi 1-chome, Shibuya-ku, Tokyo 151-8543, Japan Responsible within the United Kingdom: Casio Electronics Co. Ltd. 10 Norwich Street, London, EC4A 1BD, U.K. www.casio.co.uk	

Spanish	¡LEA ESTO!
⚠ ADVERTENCIA	
<ul style="list-style-type: none"> Si las mascotas orinan o mastican el adaptador de CA se podrá producir un cortocircuito, con riesgo de causar un incendio. 	
Si las mascotas orinan o mastican el adaptador de CA podría producirse un cortocircuito, con el consiguiente riesgo de incendio.	
<ul style="list-style-type: none"> En caso de tormenta eléctrica, no toque el dispositivo si está enchufado a la toma de corriente. 	
Los relámpagos implican el riesgo de descargas eléctricas.	
Lugares para el almacenamiento y funcionamiento	
<ul style="list-style-type: none"> No guarde ni utilice el producto en ninguno de los lugares que se describen a continuación. 	
De lo contrario, existe el riesgo de incendio y descargas eléctricas.	
<ul style="list-style-type: none"> Lugares con mucha humedad y polvo Áreas de preparación de alimentos, cerca de un humidificador o en lugares donde el producto quede expuesto a humo generado por aceites o vapor de agua Cerca de un aparato de calefacción, sobre una alfombra radiante, en lugares expuestos a la luz directa del sol, en un vehículo aparcado afuera o en cualquier otro lugar donde el producto quede expuesto a altas temperaturas. 	
<ul style="list-style-type: none"> No coloque el producto sobre un tablero inestable, sobre una superficie irregular o en cualquier otro lugar inestable. Tenga cuidado de no colocarlo en lugares como por ejemplo, alfombras con dobleces, encima del cable de alimentación, etc. 	
Asegúrese de fijar el soporte al producto.	
Asegure el soporte al producto como se describe en la documentación del usuario.	
<ul style="list-style-type: none"> No coloque objetos pesados sobre el producto. 	
La caída o vuelco del producto implica el riesgo de lesiones personales.	
No se suba al producto o soporte. (Solo modelos compatibles con el soporte)	
<ul style="list-style-type: none"> No se suba al producto ni lo balancee hacia atrás y hacia adelante. Se requiere especial atención en presencia de niños pequeños. 	
Hacerlo puede causar la caída del soporte, con el consiguiente riesgo de lesiones personales.	
Anormalidades (generación de humo, olores, calor, etc.)	
<ul style="list-style-type: none"> No utilice el producto si emite humo, olores, calor o si observa cualquier otra anomalía. No utilice el producto si se ha caído o si presenta daños. 	
De lo contrario, existe el riesgo de incendio y descargas eléctricas. Realice inmediatamente los siguientes pasos.	
<ol style="list-style-type: none"> Apague la unidad. Si está utilizando un adaptador de CA, desconecte el enchufe de la toma de corriente. Póngase en contacto con su vendedor original o con un centro de servicio CASIO. 	
Pantalla de visualización (

Français

À LIRE !

Consignes de sécurité

Merci d'avoir choisi ce produit CASIO.

Avant d'utiliser l'instrument, lisez attentivement les Consignes de sécurité contenues dans cette brochure et les Précautions d'emploi se trouvant sur le site Web de CASIO, afin de vous assurer que vous utilisez l'instrument correctement, conformément au Mode d'emploi.

• Veuillez conserver toutes les informations pour toute référence future.

⚠ DANGER	Indique quelque chose qui crée un risque majeur de mort ou de blessures corporelles graves.
------------------------------	---

⚠ AVERTISSEMENT	Indique quelque chose qui crée un risque de mort ou de blessures corporelles graves.
-------------------------------------	--

⚠ ATTENTION	Indique quelque chose qui crée un risque de blessures corporelles mineures ou dommages physiques.
---------------------------------	---

Exemples de symboles	
⚠	Le triangle (Δ) signifie que l'utilisateur doit être prudent. (L'exemple de gauche signifie qu'il y a un risque d'électrocution.)
⊘	Le cercle coupé d'une ligne (⊘) signifie que l'action indiquée ne doit pas être effectuée. Les indications dans ou près de ce symbole sont absolument interdites. (L'exemple de gauche indique que le démontage est interdit.)
⚙	Le point noir (●) signifie que l'action indiquée doit être effectuée. Les indications à l'intérieur de ce symbole décrivent les actions qu'il faut absolument effectuer. (L'exemple de gauche indique que la fiche d'alimentation doit absolument être débranchée de la prise murale.)

Si ce produit est utilisé par un enfant ou en présence d'enfants, assurez-vous toujours de la surveillance attentive d'un adulte.

N'utilisez pas le support, l'étui souple, le banc ou les pédales à d'autres fins que celles pour lesquelles ils ont été conçus.

⚠ DANGER	
------------------------------	--

Précautions concernant les piles

● **Ne laissez pas une pile entrer en contact avec de l'eau douce, de l'eau salée ou de l'humidité. N'utilisez pas une pile si elle est mouillée.**

Cela pourrait créer un risque de surchauffe, d'incendie ou de rupture.

● **Respectez les précautions ci-dessous afin d'éviter que la pile surchauffe, ou tout risque d'incendie ou de rupture.**

- N'exposez pas une pile au feu ou à la chaleur.
- Insérez la pile avec ses pôles (plus (+) et moins (-)) orientés correctement.

• Ne transportez pas ni ne rangez un pile avec un collier, des pièces de monnaie ou d'autres objets métalliques.

• N'essayez pas de démonter ni de modifier une pile, ne la percez pas avec une aiguille, ne la soumettez pas à choc important (en marchant dessus, etc.), ni n'appliquez directement de la soudure dessus.

• Ne décollez pas l'étiquette décorative collée sur la pile.

• Ne mettez pas de pile dans un four à micro-ondes, dans un sèche linge, ou dans un récipient à haute pression, etc.

• Utilisez uniquement le type de pile spécifié.

● **Immédiatement après avoir constaté une fuite de liquide, une odeur anormale, une surchauffe, une décoloration, une déformation ou toute autre anomalie de la pile, retirez très délicatement la pile du produit et/ou du chargeur. Conservez la pile retirée à l'écart du feu.**

N'utilisez pas une pile si elle présente quel que ce soit d'anormal.

Cela pourrait créer un risque de surchauffe, d'incendie ou de rupture.

● **N'utilisez pas et ne laissez pas une pile dans un endroit exposé à la lumière directe du soleil, dans une voiture garée à l'extérieur, près d'une flamme nue, près d'un radiateur, ou dans un endroit soumis à une chaleur intense.**

Cela pourrait créer un risque de surchauffe, d'incendie ou de rupture.

● **Si un fluide provenant d'une pile entre en contact avec votre peau ou vos vêtements, rincer immédiatement avec de l'eau propre.**

Ce fluide peut entraîner une irritation de la peau.

Si le fluide de la pile pénètre dans vos yeux, cela pourrait entraîner un risque de perte de vision, etc.

Rincez immédiatement les yeux à l'eau et contactez un médecin.

● **Utilisez uniquement le chargeur spécifié pour charger les piles rechargeables au nickel-métal-hydrure.**

Utiliser un autre chargeur que celui spécifié entraîne un risque de charge anormale, de surchauffe, de feu et d'explosion.

● **N'utilisez pas de piles rechargeables nickel métal hydrure qui n'ont pas été chargées complètement même si elles ont été chargées pendant plus longtemps que la durée spécifiée.**

Cela peut indiquer que les piles sont détériorées et ne peuvent pas être utilisées comme prévu, et peuvent entraîner un risque de surchauffe, d'incendie ou d'explosion.

● **Utilisez des piles nickel métal hydrure qui ont été complètement chargées en même temps.**

L'utilisation de piles avec des niveaux de charge différents peut provoquer une détérioration prématurée et créer un risque de surchauffe, d'incendie ou d'explosion.

⚠ AVERTISSEMENT	
-------------------------------------	--

Adaptateur secteur et cordon d'alimentation	
● Pour éviter tout risque d'incendie et de choc électrique de l'adaptateur secteur et du cordon d'alimentation, veillez à respecter les précautions ci-dessous.	
• Utilisez uniquement l'adaptateur secteur spécifié.	⊘
• Utilisez uniquement le cordon d'alimentation fourni.	⊘
• Utilisez l'adaptateur secteur uniquement avec l'appareil pour lequel il a été spécifié.	⊘
• Utilisez le cordon d'alimentation fourni uniquement avec ce produit.	⊘
• Ne branchez pas le cordon d'alimentation sur une prise de courant avec une mauvaise tension nominale.	⊘
• Ne recouvrez pas le cordon d'alimentation par une couverture ou autre chose pendant son utilisation et gardez le éloigné des appareils de chauffage.	⊘
• Ne placez pas d'objet lourd sur le cordon d'alimentation et ne le gardez pas enroulé pendant son utilisation.	⊘
• Ne soumettez pas un cordon d'alimentation à la chaleur, et n'essayez pas de le modifier pour éviter de l'endommager.	⊘
• Ne tordez pas, ne pliez pas ni ne tirez de façon excessive sur le cordon d'alimentation.	⊘
• Assurez-vous que le cordon d'alimentation n'est pas coincé entre le mur et l'étagère ou la table où se trouve le produit, et ne recouvrez jamais le cordon d'alimentation d'un coussin ou d'un objet.	⊘

⚠ AVERTISSEMENT	
• Si l'adaptateur secteur ou le cordon d'alimentation devait être endommagé, contactez un centre de service après-vente CASIO.	⊘
• Ne touchez pas la fiche avec les mains mouillées.	⊘
● Lorsque vous laissez le produit sans surveillance, débranchez l'adaptateur secteur et placez-le dans un endroit à l'abri des animaux.	⊘
La bave ou l'urine d'un animal domestique sur l'adaptateur secteur peut créer un risque de court-circuit qui peut entraîner un incendie.	⊘

● **En cas d'orage, ne touchez pas l'appareil branché à une prise électrique.**

- L'orage crée un risque de choc électrique.

Emplacement de stockage et d'utilisation	
● Ne rangez pas ni n'utilisez le produit dans les endroits décrits ci-dessous.	⊘
Ceci crée un risque d'incendie et de choc électrique.	⊘
• Endroits exposés à une grande quantité d'humidité et de poussière	⊘
• Endroits de préparation de nourriture, près d'un humidificateur, ou dans un endroit où le produit est exposé à de la fumée d'huile ou de la vapeur d'eau	⊘
• Prés d'un appareil de chauffage, sur un tapis chauffant, dans un endroit exposé directement aux rayons du soleil, dans une voiture garée à l'extérieur, dans n'importe quel autre endroit où le produit est soumis à des températures élevées.	⊘

● **Ne placez pas le produit sur une plateforme instable, ou une surface irrégulière, ou sur une surface qui n'est bien fixée par le haut. N'utilisez pas un dispositif de blocage de sangle endommagé.**

● **N'ouvrez pas le produit sur une plateforme instable, ou une surface irrégulière, ou sur une surface qui n'est bien fixée par le haut. N'utilisez pas un dispositif médical rencontrant une anomalie, éloignez le produit et contactez un médecin.**

Assurez-vous de fixer le support au produit.

Fixez le support au produit de façon décrite dans le mode d'emploi.

● **Ne placez pas l'objet lourd sur le produit.**

Une chute ou un renversement du produit peut entraîner un risque de blessure.

● **Ne montez pas sur le produit ni sur le support. (Modèles compatibles avec le support uniquement)**

● **Ne montez pas sur le produit ni ne le faites basculer d'avant en arrière.**

Il faut faire particulièrement attention dans les endroits où des enfants en bas âge sont présents.

Le support risquerait de se renverser, créant un risque de blessures corporelles.

● **Ne montez pas sur le produit ni ne le faites basculer d'avant en arrière.**

Il faut faire particulièrement attention dans les endroits où des enfants en bas âge sont présents.

Le support risquerait de se renverser, créant un risque de blessures corporelles.

● **Ne montez pas sur le produit ni ne le faites basculer d'avant en arrière.**

Il faut faire particulièrement attention dans les endroits où des enfants en bas âge sont présents.

● **N'appuyez pas sur l'écran LCD et ne le soumettez pas à des chocs importants.**

Le verre de l'écran LCD pourrait se casser et blesser une main.

● **Si l'écran LCD était cassé, ne touchez jamais au liquide à l'intérieur.**

Le liquide de l'écran LCD peut créer un risque d'irritation de la peau en cas de contact.

Si du liquide LCD pénètre dans votre bouche, rincez immédiatement votre bouche et contactez votre médecin.

Si du liquide LCD pénètre dans vos yeux ou sur votre feu, rincez avec de l'eau propre et contactez votre médecin.

• Si vous n'avez pas l'intention d'utiliser le produit pendant longtemps, débranchez la fiche de la prise de courant.

• Au moins une fois dans l'année, débranchez la fiche d'alimentation de la prise de courant et utilisez un chiffon sec pour enlever la poussière accumulée autour de ses broches.

• Avant de déplacer le produit, éteignez-le et débranchez-le de la prise de courant.

Ceci crée un risque de choc électrique, de brûlures et de blessures.

● **Risques de suffocation et d'étranglement**

● **Ne laissez personne jouer avec les sacs en plastique d'emballage du produit.**

Les sacs en plastique créent un risque de suffocation s'ils sont placés sur la tête, avalés, etc.

Il faut faire particulièrement attention dans les endroits où des enfants en bas âge sont présents.

● **Évitez l'eau et les matières étrangères**

● **Ne laissez pas d'eau, d'autres liquides (boissons sportives, eau de mer, urine d'animaux ou d'animaux de compagnie, etc.), ou des objets étrangers (fragments de métaux, etc.) entrer dans le produit ou l'adaptateur secteur. Si une telle matière entre dans le produit, effectuez immédiatement les étapes ci-dessous.**

Continuez d'utiliser le projecteur dans cet état présente un risque d'incendie et de choc électrique.

- Coupez le courant.
- Si vous utilisez un adaptateur secteur, débranchez sa fiche d'alimentation de la prise électrique.
- Contactez le revendeur original ou un service après-vente CASIO.

● **Ne placez aucun des objets suivants sur ou à côté du produit, de l'adaptateur secteur ou du couvercle du clavier.**

• Récipient contenant de l'eau ou un autre liquide (vase, pot de fleurs, tasse, cosmétiques, médicaments, etc.)

• Petits éléments en métal (épingles à cheveux, aiguilles à couture, pièces, etc.)

• Éléments inflammables

• Bougies ou autres objets produisant une flamme

Du liquide coulant dans le produit peut créer un risque d'incendie et de choc électrique.

Si une matière étrangère entrati dans le produit, effectuez immédiatement les étapes ci-dessous.

- Coupez le courant.
- Si vous utilisez un adaptateur secteur, débranchez sa fiche d'alimentation de la prise électrique.
- Contactez le revendeur original ou un service après-vente CASIO.

● **Ce produit**

● **Ne jetez pas le produit au feu.**

Il pourrait exploser, causant un risque d'incendie et de blessure.

● **Ne laissez pas tomber le produit et ne le soumettez pas à des chocs.**

L'emploi de ce produit endommagé crée un risque d'incendie et de choc électrique.

Si le produit est endommagé, suivez les étapes ci-dessous.

- Coupez le courant.
- Si vous utilisez l'adaptateur secteur, débranchez sa fiche d'alimentation de la prise murale.
- Contactez un centre de service après-vente CASIO.

● **Lorsque vous déplacez ce produit, veillez à utiliser vos deux mains pour le soulever.**

Sinon, vous risquez de blesser les personnes qui vous entourent ou de provoquer d'autres accidents imprévus.

⚠ AVERTISSEMENT	
-------------------------------------	--

Dispositif de blocage de sangle (modèles compatibles avec les sangles de guitare uniquement)

● **Lorsque vous manipulez le dispositif de blocage de sangle, veillez à ce que les enfants en bas âge ne l'aient pas. Rangez-le dans un endroit sûr des jeunes enfants.**

En cas d'ingestion accidentelle, contactez immédiatement un médecin.

● **Après avoir fixé une sangle de guitare, vérifiez le dispositif de blocage de sangle pour vous assurer qu'elle est bien fixée par le haut. N'utilisez pas un dispositif de blocage de sangle endommagé.**

Si le dispositif de blocage de la sangle n'est pas fixé ou s'il est mal fixé, la sangle de guitare peut se détacher, entraînant un risque de chute du produit et de dommages corporels.

● **Ne prenez pas le produit, ne le transportez pas et ne le faites pas balancer en le tenant par une sangle de guitare en vente dans le commerce.**

Cela pourrait entraîner le détachement de la sangle de la guitare, créant ainsi le risque de faire tomber le produit, et entraîner des dommages ou des blessures.

● **Équipement médical affecté par l'électromagnétisme**

● **Gardez ce produit loin de la zone du torse de toute personne équipée d'un stimulateur cardiaque.**

Les stimulateurs cardiaques et les dispositifs similaires peuvent être affectés par l'électromagnétisme. Si quelq'un équipe d'un stimulateur cardiaque ou d'un autre dispositif médical rencontrait une anomalie, éloignez le produit et contactez un médecin.

⚠ ATTENTION	
---------------------------------	--

Précautions concernant les piles

● **Respectez les précautions ci-dessous. Le non respect de ces précautions pourrait provoquer une rupture de la pile, entraînant un risque d'incendie, de blessures corporelles, et une fuite de fluide pourrait salir les objets proches.**

- Ne laissez jamais une pile être court-circuitée.
- Ne mélangez pas une vieille pile avec une pile neuve.
- N'exposez pas une pile à des différents types de piles.
- Ne chargez pas une pile non rechargeable.

• Si vous n'avez pas l'intention d'utiliser le produit pendant longtemps, retirez les piles.

• Remplacez les piles dès que possible quand elles sont usées.

• N'utilisez pas une pile dont le revêtement a été retiré.

● **N'utilisez pas une pile qui fuit.**

Ceci crée un risque d'incendie et de choc électrique. Arrêtez immédiatement d'utiliser le produit et contactez votre revendeur original ou un service après-vente CASIO.

● **Gardez les piles hors de la portée des enfants. Pendant l'utilisation, assurez-vous que des enfants en bas âge ne peuvent pas retirer les piles du produit.**

● **Ne laissez pas une pile dans un endroit utilisé par un animal domestique.**

Un animal domestique mâchant une pile peut entraîner un risque de fuite de fluide, de surchauffe, d'incendie et de rupture.

Adaptateur secteur et cordon d'alimentation	
--	--

● **Pour éviter tout risque d'incendie et de choc électrique de l'adaptateur secteur et du cordon d'alimentation, veillez à respecter les précautions ci-dessous.**

• Tenez la fiche d'alimentation pour la débrancher de la prise murale.

• N'utilisez pas de détergent pour nettoyer le cordon d'alimentation, en particulier la fiche d'alimentation et la prise.

• Insérez la fiche d'alimentation à fond dans la prise de courant.

• Si vous n'avez pas l'intention d'utiliser le produit pendant longtemps, débranchez la fiche de la prise de courant.

• Au moins une fois dans l'année, débranchez la fiche d'alimentation de la prise de courant et utilisez un chiffon sec pour enlever la poussière accumulée autour de ses broches.

• Avant de déplacer le produit, éteignez-le et débranchez-le de la prise de courant.

• Ne soumettez pas les piles à des pressions barométriques excessivement basses pendant son utilisation, son stockage ou son transport.

• Laissez les piles refroidir avant de les remplacer. Dans le cas contraire, vous risquez de vous brûler ou de vous blesser.

● **Entretien du projecteur**

● **Avant de nettoyer le produit, éteignez-le et débranchez l'adaptateur secteur de la prise de courant.**

Ceci vous évitera les risques de choc électrique.

Laissez l'adaptateur secteur branché crée un risque d'endommagement du cordon d'alimentation, d'incendie et de choc électrique.

● **Connexions**

● **Connectez uniquement les appareils et les éléments spécifiés aux connecteurs.**

N'insérez aucun objet étranger (morceaux de métal, crayons, etc.) dans les connexions.

Une connexion à d'autres appareils ou éléments crée un risque d'incendie et de choc électrique.

● **Niveau de volume**

● **N'écoutez pas à un volume très élevé pendant de longues périodes.**

Un réglage à un volume élevé peut endommager votre audition. Faites particulièrement attention lors de l'utilisation d'un casque d'écoute.

● **Sauvegarde des données importantes**

● **Effectuez toujours une copie de sauvegarde de vos données importantes en les transférant sur un ordinateur ou un autre dispositif de stockage.**

Notez que les données peuvent être effacées en cas de mauvais fonctionnement du produit, d'une réparation, etc.

● **Assemblage correct du support (Modèles compatibles avec le support uniquement)**

● **Assurez-vous de respecter les précautions ci-dessous.**

• Réalisez l'assemblage de la façon indiquée dans le mode d'emploi.

• Assurez-vous que l'instrument est correctement monté sur le support.

• Lors de la mise en place de l'instrument sur le support, faites attention de ne pas vous pincer les doigts entre les deux.

• Deux personnes ou plus doivent travailler ensemble lors du montage ou du déplacement de l'instrument.

• Lors du montage ou du déplacement de l'instrument, ne faites pas glisser ni ne penchez le support.

Si vous ne respectez pas les précautions, le support pourrait basculer et l'instrument tomber, créant un risque de blessures.

⚠ ATTENTION	
---------------------------------	--

Précautions de sécurité relatives au support (Modèles compatibles avec le support uniquement)

● **Si vous remarquez une instabilité, des vis manquantes, des vis rouillées ou tout autre problème pendant que vous jouez, contactez votre revendeur original ou un service après-vente CASIO.**

Vérifiez périodiquement s'il n'y a pas des vis desserrées. Serrez solidement les vis desserrées.

Si vous ne respectez pas les précautions, le support pourrait basculer et l'instrument tomber, créant un risque de blessures.

● **Précautions relatives à la santé (modèles de clavier éclairé uniquement)**

● **Il a été signalé que, dans de très rares cas, l'exposition à une forte lumière ou à une lumière clignotante peut provoquer des spasmes musculaires momentanés, une perte de conscience ou d'autres symptômes.**

• Les personnes qui ont déjà subi de tels symptômes doivent consulter un médecin avant d'utiliser ce produit.

• Utilisez ce produit dans un endroit bien éclairé.

• Si quelq'un présentait les symptômes décrits ici, arrêtez immédiatement d'utiliser le produit et contactez un médecin.

Banc (Modèles compatibles avec le banc uniquement)	
---	--

● **Utilisez le banc uniquement pour l'usage auquel il est destiné.**

Utiliser le banc comme objet de jeu ou comme escabeau peut entraîner son basculement, et créer un risque de blessure.

● **Ne laissez jamais plus d'une personne s'asseoir sur le banc à la fois.**

Cela pourrait entraîner un effort excessif sur la posture du joueur ou faire basculer le banc, créant ainsi un risque de blessure.

● **N'essayez jamais de régler la hauteur du banc de piano en restant assis dessus.**

Vous risqueriez de vous concner les doigts entre le cadre et le siège.

● **Vérifiez périodiquement que les écrous qui fixent le banc ou d'autres pièces ne sont pas desserrés. Utilisez la clé fournie pour serrer fermement les écrous qui sont desserrés.**

Utiliser le banc alors que les écrous sont desserrés peut entraîner le basculement ou la rupture du banc, et entraîner un risque de blessure.

● **N'utilisez pas le banc pour des personnes âgées ou de jeunes enfants.**

Un contact direct entre le caoutchouc et le revêtement de sol peut provoquer des décolorations, des marques ou d'autres dégâts.

● **Posez du feutre ou un autre type de tissu sous le banc pour des personnes âgées ou de jeunes enfants.**

Utiliser le banc sans contact direct entre le caoutchouc des pieds et la surface du sol.

Utiliser le banc sans contact direct entre le caoutchouc des pieds et la surface du sol.

● **Étui souple (modèles compatibles avec l'étui souple uniquement)**

● **Lorsque vous déplacez le produit, assurez-vous toujours que la fermeture à été fermée au préalable.**

Sinon, le produit risque de tomber et de causer des dommages ou des blessures.