

EX-10 BEST SHOT Scene Settings

The list below explains the settings that are applied for the Best Shot sample scene that are built-into the camera

November, 2013

< BEST SHOT mode >

Scene No.	TITLE	Commentary	Recording Mode	Exposure Mode	EV Shift	Flash Mode	White Balance	ISO	Metering	Filter	Sharpness	Saturation	Lighting	Contrast	Flash Intensity	Focus Mode	AF Area	Anti-shake	AF Assist	Face Detection	Make-UP	Landscape	Single SR
1	Triple Shot	Shoots a series of three images from before and after the shutter button press.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+4)	-	-
			Setting at movie	Cannot be used for movies.																			
2	Blurred Background	Blurred background makes subject stand out. Move in as close to subject as possible.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	-	-	-
			Setting at movie	Cannot be used for movies.																			
3	All-In-Focus Macro	In-focus macro shooting up to distant scenery.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	On	0	0	Macro	Multi	Standard	On	-	-	-	-
			Setting at movie	Cannot be used for movies.																			
4	HDR	Combines multiple images for best exposure, even for complex brightness conditions.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	Off	0	0	Auto Focus	Spot	Standard	On	Off	-	-	-
			Setting at movie	Cannot be used for movies.																			
5	HS Anti Shake	Records multiple images and combines them into a single image to correct image blur.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	Off	-	-	-
			Setting at movie	Cannot be used for movies.																			
6	HS Night Scene	Auto detection of handheld or tripod shooting for beautiful, blur-free night scenes.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	Off	0	0	Auto Focus	Spot	Standard	On	Off	-	-	-
			Setting at movie	↑	↑	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	-	↑	↑	↑
7	HS Night Scene and Portrait	Auto detection of handheld or tripod shooting for beautiful night scenes and portraits.	Setting at CS (still) Setting at movie	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+4)	-	-
			Setting at movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	-	-	↑	↑
8	HS Night Shot	Enables recording of an image without flash, even when lighting is dim.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	-	0	0	Auto Focus	Spot	Standard	On	On	-	-	-
			Setting at movie	Cannot be used for movies.																			
9	Multi SR Zoom	Enhanced resolution and expanded zoom range.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	Off	0	0	Auto Focus	Spot	Standard	On	Off	-	-	-
			Setting at movie	Cannot be used for movies.																			
10	HS Best Selection	Shoots multiple images, and extracts best faces for final image.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+4)	-	-
			Setting at movie	Cannot be used for movies.																			
11	Slide Panorama	Sweep the camera in the direction you want to shoot a wide panorama.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	-	0	0	Auto Focus	Spot	-	On	On	-	-	-
			Setting at movie	Cannot be used for movies.																			
12	Wide Shot	Sweep the camera to shoot a wide image.	Setting at CS (still) Setting at movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	-	0	0	Auto Focus	Spot	-	On	On	-	-	-
			Setting at movie	Cannot be used for movies.																			
13	Brightning	Brightens faces. Setting zoom to telephoto blurs the background.	Setting at still snapshots Setting at still movie	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+6)	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	-	-	↑	-
14	Scenery	Hard sharpness High saturation	Setting at still snapshots Setting at still movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	Off	Off	-	Vivid Landscape +1	*1
			Setting at still movie	↑	↑	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	↑	↑	-	-

Scene No.	TITLE	Commentary	Recording Mode	Exposure Mode	EV Shift	Flash Mode	White Balance	ISO	Metering	Filter	Sharpness	Saturation	Lighting	Contrast	Flash Intensity	Focus Mode	AF Area	Anti-shake	AF Assist	Face Detection	Make-UP	Landscape	Single SR
15	Portrait With Scenery	Enhanced flesh tones Setting zoom to wide angle simplifies focusing.	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+4)	Vivid Landscape +1	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	-	-	-
16	Children	Enhanced flesh tones and a fast shutter speed.	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+2)	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	-	↑
17	Sports	Fast shutter speed	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	Off	Off	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	-	↑
18	Candlelight Portrait	Soft sharpness and tungsten white balance Keep the camera still!	Setting at still snapshots	Program AE	0	Flash Off	Tungsten	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+4)	-	*1
			Setting at still movie	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	-	↑
19	Party	Fast shutter speed	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	On	On (+6)	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	-	↑
20	Pet	Fast shutter speed Shoot from the eye level of your pet.	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	Off	-	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	-	↑	↑
21	Flower	Macro Mode High saturation	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	-1	+1	On	0	0	Macro	Spot	Standard	On	Off	-	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	↑	↑
22	Natural Green	Hard sharpness and high saturation enhance green hues.	Setting at still snapshots	Program AE	0	Auto Flash	Daylight	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	Off	-	Vivid Landscape +1	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	↑	↑	-
23	Autumn Leaves	Hard sharpness and high saturation enhance red hues.	Setting at still snapshots	Program AE	0	Auto Flash	Daylight	Auto	Multi	-	+1	+1	On	+2	0	Auto Focus	Spot	Standard	On	Off	-	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	-	Camera AS	-	-	↑	↑
24	Soft Flowing Water	Slow shutter speed	Setting at still snapshots	Program AE	0	Flash Off	Daylight	ISO80	Multi	-	-1	0	Off	0	0	Auto Focus	Spot	Standard	On	Off	-	-	-
			Setting at still movie	↑	↑	↑	↑	Auto	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	↑	↑
25	Splashing Water	Fast shutter speed	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	Off	-	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	↑	↑
26	Sunset	Red filter Daylight white balance	Setting at still snapshots	Program AE	0	Flash Off	Daylight	Auto	Multi	Red	-1	+1	Off	0	0	Infinity	-	Standard	Off	-	-	-	*1
			Setting at still movie	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	↑	↑
27	Fireworks	Slow shutter speed Infinity focus Keep the camera still!	Setting at still snapshots	Shutter Speed: 2sec Aperture: Open	0	Flash Off	Daylight	ISO80	Center Weighted	-	0	0	Off	0	0	Infinity	-	-	On	-	-	-	-
			Setting at still movie	Program AE	↑	↑	↑	Auto	Multi	↑	↑	↑	-	↑	-	↑	↑	↑	-	-	↑	↑	↑
28	Food	Macro Mode High saturation	Setting at still snapshots	Program AE	0	Auto Flash	Auto	Auto	Multi	-	0	+1	On	0	0	Macro	Spot	Standard	On	Off	-	-	*1
			Setting at still movie	↑	↑	Flash Off	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	↑	↑
29	Text	Macro Mode Hard sharpness High contrast	Setting at still snapshots	Program AE	+1EV	Flash Off	Auto	Auto	Center Weighted	-	+1	0	Off	+1	0	Macro	Spot	Standard	On	Off	-	-	*1
			Setting at still movie	↑	↑	↑	↑	↑	↑	↑	↑	↑	↑	-	↑	-	↑	↑	Camera AS	-	-	↑	↑

Scene No.	TITLE	Commentary	Recording Mode	Exposure Mode	EV Shift	Flash Mode	White Balance	ISO	Metering	Filter	Sharpness	Saturation	Lighting	Contrast	Flash Intensity	Focus Mode	AF Area	Anti-shake	AF Assist	Face Detection	Make-UP	Landscape	Single SR	
30	Prerecord (Movie)	Continually pre-records movie images, which are saved when [MOVIE] is pressed.	Setting at still snapshots	Cannot be used for snapshots.																				
			Setting at still movie	Program AE	0	Flash Off	Auto	Auto	Multi	-	0	0	-	0	0	Auto Focus	-	Camera AS	-	-	-	-	-	-
31	HDMI TV Output	Displays camera screen contents on a TV over an HDMI cable connection.	Setting at CS (still)	Program AE	0	Auto	Auto	Auto	Multi	-	0	0	On	0	0	Auto Focus	Spot	Standard	On	-	-	-	-	*1
			Setting at movie	Cannot be used for movies.																				

*1: Reflects the Auto Mode setting (On or Off). Setting can be changed after selecting a BEST SHOT scene.