			EX-ZR55	EX-ZR65	EX-ZR2000	EX-ZR3500	EX-ZR3600	EX-ZR5500 *6	EX-FR100 *6/ EX-FR100CA *6	EX-FR100 Ver2.50 *8/ EX-FR100L *8	EX-FR200 *7	EX-TR550	EX-TR600	EX-TR750 *7
	View on Phone	Viewing Snapshots	0	0	0	0	0	0	0	0	0	0	0	0
		Copying Camera Images to a Smartphone	0	0	0	0	0	0	0	0	0	0	0	0
		Protecting a Camera Image	×	0	×	×	0	0	0	0	0	×	0	0
		Deleting Camera Images	×	0	×	×	0	0	0	0	0	×	0	0
		Changing the Displayed Image to a Full-screer view	0	0	0	0	0	0	0	0	0	0	0	0
	Remote Capture	Shooting a Snapshot	0	Ω	Ω	Ω	Ω	Ο	Ω	0	0	Ω	Ω	Ο
		Shoot with High Speed CS	Ö	Õ	Ö	Ö	Õ	Ŏ	Õ	ŏ	Ö	×	×	×
		Adding Geo Tags to Images	Õ	Õ	Ö	Õ	Õ	Ö	Õ	Ö	Õ	Ô	Ô	Ö
		Interval Shooting	×	×	×	×	×	×	Õ	Ö	Õ	×	×	×
		Using Auto Send	Ô	0	Ô	Ö	Ô	Ö	Õ	ŏ	ŏ	Ô	Ö	Ö
		Changing the Displayed Image to a Full-screer		0	0	0	0	0	0	0	0	0	0	0
	Setting UP the camera	view Change WLAN password	×	×	×	×	×	×	0	0	0	×	×	×
		Adjusting Date and Time	×	Ô	×	×	Ô	Ô	0	0	0	×	Ô	<u>,</u>
		Using Auto Send	×	0		×	0	0	0	0	0		0	0
		Using Auto Send	×	0	×	×	0	0	U	U	0	×	0	U
Function added in Ver 3.0 or later	Adding location information to images received from the camera		×	0	×	×	0	0	×	×	×	×	×	×
	One Time Share		×	0	×	×	0	0	×	×	×	×	×	×
Function added in Ver 4.0 or later	Remote Capture	Snapshot size	×	×	×	×	×	×	O*3	0	×	×	×	×
		Movie quality	×	×	×	×	×	×	O*3	0	O*4	×	×	×
		Movie stabilizer	×	×	×	×	×	×	O*3	0	O*4	×	×	×
		Battery indicator	×	×	×	×	×	×	O*3	0	O*4*5	×	×	×
		Memory indicator	×	×	×	×	×	×	O*3	0	O*4*5	×	×	×
	Setting UP the camera	Camera sound	×	×	×	×	×	×	O*3	0	O*4*5	×	×	×
		Camera version information	×	×	×	×	×	×	O*3	0	O*4*5	×	×	×
		Camera reset	×	×	×	×	×	×	O*3	Ö	O*4*5	×	×	×
		Format camera memory	×	×	×	×	×	×	O*3	0	O*4*5	×	×	×
	Multi Pairing *1		0	0	0	0	0	0	0	Ö	×	0	0	0
	Transition to EXILIM ALBUM		ŏ	Ö	ŏ	ŏ	Ŏ	ŏ	Ŏ	Ŏ	Ö	ŏ	Ŏ	Ŏ
	Converting movies to MP4 files *2		Ö	Ö	Ö	Ö	Ö	Ö	Ö	Ö	Ö	Ö	Ö	Ö
Function added in Ver 4.1 or later	Remote Capture	Double Save (Dome View)	×	×	×	×	×	×	×	×	O*4	×	×	×

^{*1} Up to two cameras can be registered at one time.

^{*2} Supported by Android version only.
*3 Camera firmware version 2.00 or higher.
*4 Camera firmware version 1.10 or higher.

⁴ Carriera Illinware version 1.1 or higher.
5 EXILIM Connect version 4.1 or higher.
6 To use with this camera, EXILIM Connect Ver 4.0 or higher is required.
7 To use with this camera, EXILIM Connect Ver 4.1 or higher is required.

^{*8} To use with this camera, you need the version of EXILIM Connect described below. iOS: EXILIM Connect Ver 4.1.9 or higher Android terminal: EXILIM Connect Ver 4.1.2 or higher