

Appendix • Apéndice • Anhang • Appendice • Appendix • Appendice • Bilaga • Apêndice • 附录 • 附錄 • الملحق

音色リスト • Tone List • Lista de sonidos • Klangfarben-Liste • Liste des sonorités • Toonlijst • Elenco dei timbri • Tonlista • Lista de sons • 音色表 • 音色彩 • جدول النوتة الموسيقية • جنول النوتة الموسيقية

- ① No. • No. • № • Nr. • No. • Nr. • Num. • Nr. • № • 番号 • 編號 • رقم
 ② 音色名 • Tone name • Nombre de sonido • Klangfarben-Name • Nom des sonorités • Toonnaam • Nome del tono • Tonnamn • Nome do som • 音色名 • 音色彩 • اسم النغمة
 ③ プログラムチェンジ • Program Change • Cambio de programa • Klangprogramm-Wechsel • Changement de programme • Programma-verandering • Cambiamento programma • Program-ändring •
 Mudança de programa • 程序变化 • 程式變化 • تغییر البرنامج
 ④ بانکسелеکت MSB • Bank Select MSB • MSB de selección de banco • Bankwahl MSB • MSB de sélection de banque • Bankkeuze MSB • MSB di selezione banco • Bankval MSB • MSB de seleção de banco •
 庫選擇 MSB • 庫選擇 MSB • MSB الیکتاب
 ⑤ 最大同時発音数 • Maximum Polyphony • Polifonía máxima • Max. Polyphonie • Polyphonie maximale • Maximale polyfonie • Polifonia massima • Maximal polyfoni • Polifonia máxima • 最大多重音 • 最大多重音 •
 الحد الأقصى لعدد الأصوات
 ⑥ 音域タイプ • Range Type • Tipo de gama • Bereichstyp • Type de registre • Bereiktype • Tipo di gamma • Omfångstyp • Tipo de gama • 音域类型 • 音域類型 • نوع المدى

●	●	●	●	●	
001	STEREO GRAND PIANO	0	2	24	A
002	GRAND PIANO	0	1	48	A
003	BRIGHT PIANO	0	2	48	A
004	MELLOW PIANO	1	3	48	A
005	MODERN PIANO	1	3	24	A
006	DANCE PIANO	1	1	48	A
007	STRINGS PIANO	0	8	24	A
008	HONKY-TONK	3	2	24	A
009	OCTAVE PIANO	3	9	24	A
010	ELEC. GRAND PIANO	2	2	48	A
011	MODERN E.G.PIANO	2	3	24	A
012	HARPSICHORD	6	2	48	A
013	COUPLED HARPSICHORD	6	8	24	A
014	HARPSICHORD & STRINGS	6	1	24	A
ELECTRIC PIANO					
015	ELEC.PIANO	4	2	48	A
016	FM ELEC.PIANO	5	5	48	A
017	60'S ELEC.PIANO	4	5	48	A
018	CHORUS EP 1	4	9	24	A
019	CHORUS EP 2	4	6	24	A
020	MODERN E.PIANO	5	2	24	A
021	SOFT E.PIANO	4	8	48	A
022	SYNTH-STR.E.PIANO	4	1	24	A
023	CLEAN E.PIANO	4	4	24	A
024	CLAVI 1	7	2	48	A
025	SOFT CLAVI	7	1	48	A
026	CLAVI 2	7	3	48	A
027	DETUNE CLAVI	7	8	24	A
028	SEQUENCE CLAVI	7	9	48	A
CHEMATIC PERC.					
029	CELESTA 1	8	2	48	A
030	GLOCKENSPIEL	9	2	48	B
031	MUSIC BOX 1	10	2	24	A
032	VIBRAPHONE 1	11	2	48	A
033	MARIMBA	12	2	48	A
034	XYLOPHONE	13	2	48	A
035	CELESTA 2	8	1	24	A
036	MUSIC BOX 2	10	1	24	A
037	VIBRAPHONE 2	11	1	48	A
038	SOFT VIBRAPHONE 1	11	3	24	A
039	SOFT VIBRAPHONE 2	11	4	24	A
040	SOFT MARIMBA	12	1	24	A
041	TUBULAR BELL	14	2	48	A
042	DULCIMER	15	2	24	A
ORGAN					
043	DRAWBAR ORGAN 1	16	2	24	A
044	DRAWBAR ORGAN 2	16	1	48	A
045	CHURCH ORGAN 1	19	2	24	A
046	PERC.ORGAN 1	17	2	24	A
047	PERC.ORGAN 2	17	3	24	A
048	CLICK ORGAN	18	7	24	A
049	ELEC.ORGAN 1	16	4	24	A
050	ELEC.ORGAN 2	16	4	24	A
051	JAZZ ORGAN 1	17	4	24	A
052	ROCK ORGAN 1	18	2	24	A
053	CHAPEL ORGAN	19	8	24	A
054	REED ORGAN	20	2	48	A
055	ACCORDION 1	21	2	24	A
056	BANDONEON 1	23	2	24	A
057	BANDONEON 2	23	1	24	A
058	HARMONICA 1	22	2	48	A
059	HARMONICA 2	22	8	48	A
060	THEATER ORGAN	19	6	24	A
061	JAZZ ORGAN 2	17	6	24	A
062	ROCK ORGAN 2	18	1	24	A
063	ORGAN	17	5	24	A
064	FULL DRAWBAR	16	9	24	A
065	CHURCH ORGAN 2	19	3	24	A
066	ACCORDION 2	21	3	24	A
GUITAR					
067	NYLON STR.GUITAR	24	2	48	C
068	STEEL STR.GUITAR	25	2	48	C
069	12 STR.GUITAR	25	8	24	C
070	JAZZ GUITAR	26	2	48	C
071	OCT JAZZ GUITAR	26	8	24	C
072	CLEAN GUITAR 1	27	2	48	C
073	CLEAN GUITAR 2	27	1	24	C
074	MUTE GUITAR	28	2	48	C
075	OVERDRIVE GT	29	2	48	C
076	DISTORTION GT	30	2	24	C
077	POWER DIST. GT	30	5	24	C
078	FEEDBACK GT	31	8	24	C
079	CHORUS STEEL GT	25	9	24	C
080	DIST.GT & BASS	30	6	24	C
BASS					
081	ACOUSTIC BASS	32	2	48	C
082	HIDE BASS	32	32	24	C
083	FINGERED BASS	33	2	48	C
084	PICKED BASS	34	2	48	C
085	FRETLESS BASS	35	2	48	C
086	SLAP BASS	37	2	48	C
087	SAW SYNTH-BASS	38	2	24	C
088	SQUARE SYNTH-BASS	39	2	48	C
089	DIGI ROCK BASS	39	1	24	C
090	TRANCE BASS	38	4	48	C
091	BASS & KICK	39	3	24	C
092	SINE BASS	39	6	48	C
STRICHORCHESTRA					
093	VIOLIN	40	2	48	A
094	SLOW VIOLIN	40	8	48	A
095	VIOLA	41	2	24	A
096	CELLO	42	2	24	C
097	CONTRABASS	43	2	48	C
098	PIZZICATO STRINGS	45	2	48	A
099	HARP 1	46	2	48	A
100	SLOW CELLO	42	1	24	C
101	VIOLIN & CELLO	40	3	24	A
102	CELLO SECTION	42	4	24	C
103	CHORUS HARP	46	8	24	A

●	●	●	●	●	
104	HARP 2	46	1	48	A
ENSEMBLE					
105	STRINGS	48	2	48	A
106	SLOW STRINGS	49	2	48	A
107	WIDE STRINGS	48	16	24	A
108	OCTAVE STRINGS	48	32	24	A
109	CHAMBER	48	3	24	A
110	STRINGS SFZ	48	8	48	A
111	SYNTH-STRINGS 1	50	2	24	A
112	SYNTH-STRINGS 2	51	2	24	A
113	SYNTH-STRINGS 3	51	3	24	A
114	CHOIR AAHS	52	2	48	A
115	VOICE DOO	53	2	48	A
116	SYNTH-VOICE	54	2	48	A
117	SYNTH-VOICE PAD	54	8	48	A
118	ORCHESTRA HIT 1	55	2	24	A
119	TREMOLO STRINGS	49	1	48	A
120	FLUTE & STRINGS	49	3	24	A
121	CHOIR STRINGS	52	3	24	A
122	CHORUS SYNTH-VOICE	54	9	24	A
123	ORCHESTRA HIT 2	55	1	24	A
124	FANTASY STRINGS	50	3	24	A
BRASS					
125	TRUMPET	56	2	48	A
126	TROMBONE	57	2	48	C
127	TUBA	58	2	48	C
128	MUTE TRUMPET	59	2	48	A
129	FRENCH HORN	60	2	48	C
130	BRASS	61	2	48	A
131	BRASS SECTION 1	61	3	24	A
132	BRASS SECTION 2	61	6	24	A
133	BRASS SECTION 3	61	7	24	A
134	TRUMPET SFZ	61	2	48	A
135	BRASS & STRINGS	61	4	24	A
136	HARD BRASS	61	5	48	A
137	ANALOG SYNTH-BRASS 1	62	8	48	A
138	SYNTH-BRASS 1	62	2	24	A
139	SYNTH-BRASS 2	63	2	24	A
140	MELLOW TRUMPET	56	8	48	A
141	TRUMPET SFZ	56	1	48	A
142	FRENCH HORN SECTION	60	1	24	C
143	MELLOW BRASS	61	1	48	A
144	ANALOG SYNTH-BRASS 2	62	9	24	A
REED/PIPE					
145	SOPRANO SAX 1	64	2	48	A
146	SOPRANO SAX 2	64	1	48	A
147	ALTO SAX 1	65	1	48	C
148	ALTO SAX 2	65	2	48	C
149	BREATHY A.SAX	65	8	24	C
150	HARD A.SAX	65	3	48	C
151	TENOR SAX	66	1	48	C
152	BREATHY T.SAX	66	8	24	C
153	BARITONE SAX 1	67	2	48	C
154	BARITONE SAX 2	67	1	48	C
155	OBOE	68	2	48	A
156	BASSOON	70	5	48	C
157	CLARINET	71	2	48	A
158	SAX SECTION	65	9	24	C
159	SOFT T.SAX	66	6	24	C
160	PICCOLO	72	2	48	B
161	FLUTE 1	73	2	48	A
162	FLUTE 2	73	1	24	A
163	PURE FLUTE	73	8	48	A
164	RECORDER	74	2	48	A
165	PAN FLUTE	75	2	24	A
166	BOTTLE BLOW 1	76	2	24	A
167	SHAKUHACHI	77	2	24	A
168	WHISTLE	78	2	48	A
169	OCARINA	79	2	48	A
170	BOTTLE BLOW 2	76	1	24	A
171	FLUTE & OBOE	73	3	24	A
172	SOLO OBOE	68	4	48	A
SYNTH-LEAD					
173	SQUARE LEAD 1	80	2	24	A
174	SQUARE PULSE LEAD	80	5	24	A
175	SEQUENCE LEAD 1	83	5	24	A
176	SAW LEAD 1	81	2	24	A
177	MELLOW SAW LEAD	81	8	48	A
178	SEQUENCE SAW	81	32	24	A
179	SINE LEAD	80	8	48	A
180	SR LEAD	81	3	24	A
181	CALLOPE	82	2	24	A
182	VENT LEAD	82	5	24	A
183	CHIFF LEAD	83	2	24	A
184	CHARANG	84	2	24	A
185	VOICE LEAD	85	2	24	A
186	FIFTH LEAD	86	4	24	A
187	BASS-LEAD	87	2	24	A
188	SQUARE LEAD 2	80	3	24	A
189	SEQUENCE SQUARE	80	7	48	A
190	SEQUENCE PULSE	80	16	24	A
191	SQARE LEAD 3	80	1	48	A
192	SAW LEAD 2	81	1	48	A
193	SAW LEAD 3	81	5	24	A
194	SLOW SAW LEAD	81	4	48	A
195	FIFTH SEQUENCE	86	1	24	A
196	SEQUENCE SINE	80	9	48	A
197	PURE SYNTH	82	1	24	A
198	PURE LEAD	82	4	24	A
199	DISTORTION LEAD	84	8	24	A
200	CHURCH LEAD	85	7	24	A
201	SYNTH-VOICE LEAD	85	7	24	A
202	FIFTH SAW LEAD	86	2	24	A
203	FIFTH SQUARE LEAD	86	3	24	A
204	SEQUENCE LEAD 2	83	3	24	A
SYNTH-PAD					
205	FANTASY 1	88	2	24	A
206	FANTASY 2	88	3	24	A
207	WARM PAD	89	2	24	A
208	WARM VOX	89	8	24	A

●	●	●	●	●	
209	SINE PAD	89	3	24	A
210	POLYSYNTH 1	90	2	24	A
211	POLY SAW	90	8	24	A
212	SPACE STRINGS PAD	91	3	24	A
213	SPACE CHOIR	91	1	24	A
214	BOWED PAD	92	2	24	A
215	GLASS PAD	92	3	24	A
216	ETHNIC PAD	93	2	24	A
217	HALO PAD	94	2	24	A
218	RAIN DROP	96	2	24	A
219	SOUND TRACK 1	97	2	24	A
220	SOUND TRACK 2	97	3	24	A
221	RAVE	97	8	24	A
222	CRYSTAL	98	2	24	A
223	ATMOSPHERE	99	2	24	A
224	BRIGHTNESS	100	2	24	A
225	GOBLIN	101	2	24	A
226	ECHO PAD	102	2	24	A
227	STAR THEME	103	2	24	A
228	SPACE PAD	103	8	24	A
229	NEW AGE PAD	88	1	24	A
230	SOFT PAD	89	4	24	A
231	HORN PAD	89	5	24	A
232	POLYSYNTH 2	232	3	24	A
233	OLD TAPE PAD	89	6	24	A
234	HEAVEN	91	2	24	A
235	SQUARE PAD	92	1	24	A
236	HARD METAL PAD	93	4	24	A
237	CH				

ドラム音色リスト・Drum Assignment List・Lista de sonidos de batería・Drum-Belegungsliste・Liste des sons de percussions・Drumklankenlijst・Lista di assegnazione suoni di batteria・Lista över trumtilldelning・Lista de atribuições de bateria・鼓音分配表・鼓音分配表・قائمة تعيين الطبلية

←：STANDARD SETと同じ・indicates the same sound as STANDARD SET.・indica el mismo sonido que STANDARD SET.・bezeichnet den gleichen Sound wie STANDARD SET.・indique le même son que STANDARD SET.・geeft hetzelfde geluid aan als STANDARD SET.・indica lo stesso suono di STANDARD SET.・anger samma ljud som STANDARD SET.・indica o mesmo som que STANDARD SET.・表示与STANDARD SETの声音相同・表示與STANDARD SETの聲音相同・تشير إلى نفس المجموعة القياسية

- ① 音名・Key・Clave・Taste・Touche・Klaviertoets・Tasto・Tangent・Escala・音調・音調・المنح
- ② ノートナンバー・Note No.・Número de nota・Noten-Nr.・Número de note・Nootnummer・Numero di nota・Notnummer・Nº da nota・音符编号・音符編號・رقم النوتة
- ③ ドラムセット名・DRUMS SET NAME

①	②	③					
		STANDARD SET	ROOM SET	POWER SET	SYNTH SET	BRUSH SET	ORCHESTRA SET
C-1	0	Xiao Luo	←	←	←	←	←
	C- 1	1	←	←	←	←	←
D-1	2	Bang Guo	←	←	←	←	←
	E- 1	3	←	←	←	←	←
E-1	4	Tabla Na	←	←	←	←	←
F-1	5	Appalause	←	←	←	←	←
	F- 1	6					
G-1	7						
	A- 1	8					
A-1	9						
	B- 1	10					
B-1	11						
	C- 0	12					
C0	13						
	E 0	14					
E0	15						
	F 0	16					
F0	17						
	F 0	18					
G0	19						
	A 0	20					
A0	21						
	B 0	22					
B0	23						
	C 1	24					
C1	25						
	D 1	26					
D1	27						
	E 1	28					
E1	29						
	F 1	30					
F1	31						
	A 1	32					
A1	33	Metronome Click	←	←	←	←	←
	B 1	34	←	←	←	←	←
B1	35	Standard Kick 2	Room Kick 2	Power Kick 2	Synth Kick 2	←	←
	C 2	36	Room Kick 1	Power Kick 1	Synth Kick 1	←	←
C2	37	Slide Slick	←	←	←	←	←
	D 2	38	Room Snare 1	Power Snare 1	Synth Snare 1	Brush Snare 1	←
D2	39	Standard Hand Clap	←	Power Hand Clap	Synth Hand Clap	Brush Slap	←
	E 2	40	Standard Snare 2	Room Snare 2	Power Snare 2	Synth Snare 2	Brush Snare 2
E2	41	Low Tom 2	←	←	←	Synth Low Tom 2	Brush Low Tom 2
	F 2	42	Closed Hi-Hat	←	←	←	←
F2	43	Low Tom 1	←	←	←	Synth Low Tom 1	Brush Low Tom 1
	A 2	44	Pedal Hi-Hat	←	←	←	←
A2	45	Mid Tom 2	←	←	←	Synth Mid Tom 2	Brush Mid Tom 2
	B 2	46	Open Hi-Hat	←	←	←	←
B2	47	Mid Tom 1	←	←	←	Synth Mid Tom 1	Brush Mid Tom 1
	C 3	48	High Tom 2	←	←	←	←
C3	49	Crash Cymbal 1	←	←	←	Synth High Tom 2	Brush High Tom 2
	D 3	50	High Tom 1	←	←	←	←
D3	51	Ride Cymbal 1	←	←	←	Synth High Tom 1	Brush High Tom 1
	E 3	52	Ride Cymbal 1	←	←	←	←
E3	53	Chinese Cymbal	←	←	←	←	←
	F 3	54	Ride Bell	←	←	←	←
F3	55	Tambourine	←	←	←	←	←
	A 3	56	Splash Cymbal	←	←	←	←
A3	57	Cowbell	←	←	←	←	←
	B 3	58	Crash Cymbal 2	←	←	←	←
B3	59	Vibrastap	←	←	←	←	←
	C 4	60	Ride Cymbal 2	←	←	←	←
C4	61	High Bongo	←	←	←	←	←
	D 4	62	Low Bongo	←	←	←	←
D4	63	Mute High Conga	←	←	←	←	←
	E 4	64	Open High Conga	←	←	←	←
E4	65	Open Low Conga	←	←	←	←	←
	F 4	66	High Timbale	←	←	←	←
F4	67	Low Timbale	←	←	←	←	←
	A 4	68	High Agogo	←	←	←	←
A4	69	Low Agogo	←	←	←	←	←
	B 4	70	Cabassa	←	←	←	←
B4	71	Maracas	←	←	←	←	←
	C 5	72	Short High Whistle	←	←	←	←
C5	73	Long Low Whistle	←	←	←	←	←
	D 5	74	Short Guiro	←	←	←	←
D5	75	Long Guiro	←	←	←	←	←
	E 5	76	Claves	←	←	←	←
E5	77	High Wood Block	←	←	←	←	←
	F 5	78	Low Wood Block	←	←	←	←
F5	79	Mute Cuica	←	←	←	←	←
	A 5	80	Open Cuica	←	←	←	←
A5	81	Mute Triangle	←	←	←	←	←
	B 5	82	Open Triangle	←	←	←	←
B5	83	Shaker	←	←	←	←	←
	C 6	84					
C6	85						
	E 6	86					
E6	87						
	F 6	88					
F6	89						
	A 6	90					
A6	91	"One"	←	←	←	←	←
	B 6	92	"Two"	←	←	←	←
B6	93	"Three"	←	←	←	←	←
	C 7	94	"Four"	←	←	←	←
C7	95	"Five"	←	←	←	←	←
	D 7	96					
D7	97						
	E 7	98					
E7	99						
	F 7	100					
F7	101						
	A 7	102					
A7	103						
	B 7	104					
B7	105						
	C 8	106					
C8	107						
	D 8	108					
D8	109						
	E 8	110					
E8	111						
	F 8	112					
F8	113						
	A 8	114					
A8	115						
	B 8	116					
B8	117						
	C 9	118					
C9	119						
	D 9	120					
D9	121						
	E 9	122					
E9	123						
	F 9	124					
F9	125						
	G 9	126					
G9	127						

リズムリスト・Rhythm List・Lista de ritmos・Rhythmus-Liste・Liste des rythmes・Ritmelijs・Lista dei ritmi・Rytmlista・Lista de ritmos

节奏表・節奏表・قائمة الإيقاع

- ① No.・No.・Nº・Nr.・No.・Nr.・Num.・Nr.・Nº・编号・編號・رقم
- ② リズム名・Rhythm Name・Nombre de ritmo・Rhythmus-Name
- Nom des rythmes・Ritmenaam・Nome del ritmo・Rytmnamn・Nome do ritmo
- 节奏名・節奏名・اسم الإيقاع

①	②	③	
	8 BEAT / 16 BEAT	WORLD AMERICAN	
001	FUNK 8 BEAT	092	COUNTRY 8 BEAT
002	STRAIGHT 8 BEAT	093	COUNTRY BALLAD
003	MELLOW 8 BEAT	094	COUNTRY SHUFFLE
004	MODERN 8 BEAT	095	COUNTRY WALTZ
005	GIUITAR 8 BEAT	096	BLUEGRASS
006	8 BEAT POP	097	DIXIE
007	8 BEAT	098	TEX-MEX
008	60'S 8 BEAT	099	FAST GOSPEL
009	16 BEAT 1	100	SLOW GOSPEL
010	16 BEAT 2	101	HAWAIIAN
011	16 BEAT SHUFFLE 1		
012	16 BEAT SHUFFLE 2	SPANISH/EASTERN EUROPEAN	
	BALLAD	102	PASODOBLE
013	MODERN BALLAD	103	FOLKLORE
014	SLOW BALLAD	104	CAUCASIAN
015	16 BEAT BALLAD	105	RUSSIAN CHANSON
016	SOUL BALLAD	106	POLISH WALTZ
017	POP BALLAD 1	ARABIC/ORIENTAL	
018	POP BALLAD 2	107	SIRTAKI
019	6/8 BALLAD	108	MUS
020	ROCK BALLAD 1	109	ADANI
021	ROCK BALLAD 2	110	BALADI
	DANCE	111	KHALLUJ
022	HIP-HOP	112	MALFOOF
023	RAP POP	INDIAN	
024	DANCE POP	113	BHANGRA
025	DISCO POP	114	DADRA
026	TECHNO POP	115	GARBA
027	TRANCE	116	KEHARWA
028	MODERN R&B 1	117	TEEN TAAL
029	MODERN R&B 2	CHINESE	
030	MODERN DANCE	118	JIANGNAN
031	DISCO SOUL	119	DONGBEIYANGGE
	POPS	120	JINGJU
032	POP 1	121	HUANGMEIXI
033	POP 2	122	MIAOZU
034	POP ROCK	123	XINJIANG
035	GIUITAR POP	MALAYSIAN	
036	FAST SOUL	124	KRONCONG
037	SLOW SOUL	125	DANGDUT
038	60'S SOUL	JAPANESE	
	ROCK	126	ENKA
039	STRAIGHT ROCK	VARIOUS	
040	SHUFFLE ROCK 1	127	CHRISTMAS SONG
041	SHUFFLE ROCK 2	128	CHRISTMAS WALTZ
042	BLUES	129	SYMPHONY
043	SOFT ROCK	130	STR QUARTET
044	LATIN ROCK	PIANO RHYTHMS	
045	MODERN ROCK	131	PIANO 8 BEAT
046	SLOW ROCK	132	PIANO BALLAD 1
047	50'S ROCK	133	PIANO BALLAD 2
048	NEW ORLNS R&R	134	EP BALLAD 1
049	ROCK WALTZ	135	EP BALLAD 2
	JAZZ	136	BLUES BALLAD
050	SLOW BIG BAND	137	JAZZ COMBO 2
051	MIDDLE BIG BAND	138	JAZZ COMBO 3
052	FAST BIG BAND	139	RAGTIME
053	SWING 1	140	PIANO ROCK & ROLL
054	SWING 2	141	BOOGIE-WOOGIE
055	SLOW SWING	142	ARPEGGIO 1
056	JAZZ WALTZ 1	143	ARPEGGIO 2
057	JAZZ WALTZ 2	144	ARPEGGIO 3
058	FOX TROT	145	6/8 MARCH
059	QUICKSTEP	146	MARCH 3
060	JAZZ COMBO 1	147	STRIDE PIANO
	EUROPEAN	148	WALTZ 2
061	SCHLAGER	149	WALTZ 3
062	POLKA	150	WALTZ 4
063	POP POLKA		
064	WALTZ 1		
065	SLOW WALTZ		
066	VIENNESE WALTZ		
067	FRENCH WALTZ		
068	SERENADE		
069	TANGO		
070	MARCH 1		
071	MARCH 2		
	LATIN		
072	BOSSA NOVA 1		
073	BOSSA NOVA 2		
074	BEGUINE		