


# Quick Reference




This section provides a quick overview of keyboard operation using steps one and two of the 3-step lesson feature.

## To play the keyboard

1. Press the **POWER button** to turn on power.
  - This causes the power indicator to light.




2. Set the **MODE switch** to NORMAL.




3. Press the **SONG BANK button**.
4. Find the tune you want to play in the **Song Bank List**, and then use the **number buttons** to input its two-digit number.  
*Example:* To select "21 TWINKLE TWINKLE LITTLE STAR", input 2 and then 1.




5. Press the **STEP 1 button** or **STEP 2 button**.
  - The keyboard sounds a count beat and waits for you to play something on the keyboard. The keys that you need to press first flash.
6. Play the melody along with the selected tune's accompaniment.
  - Play in accordance with the fingerings, notes, and dynamic marks that appear on the display.



- If you selected lesson Step 1**
- Play the notes on the keyboard.
  - A sub-melody (obligato) plays in time with the melody.
  - With Step 1, the correct melody note is played no matter which keyboard key you press.



- If you selected lesson Step 2**
- Play the correct notes on the keyboard.



- Press the keyboard key that lights. Note that with tunes 70 through 99, the keyboard key light turns off as soon as you press the key.
- The keyboard key for the next note you will need to play flashes.
- A sub-melody (obligato) plays in time with the melody, as long as you press the correct keyboard keys.