

## Android, iOS Function Comparison Chart

✓	Supported
✗	Not supported
✓	More functions than Android Wear 1.x

The initial setup of your smart watch requires use with a phone running the Android OS or iOS.  
Wi-Fi environment required for iOS connection.

Item			Smart Outdoor Watch PRO TREK Smart WSD-F20/F20S			Smart Outdoor Watch WSD-F10				
			Android Wear 2.0			Android Wear 2.0			Android Wear 1. x	
			Android	iPhone	Supported with Watch Alone (No network connection)	Android	iPhone	Supported with Watch Alone (No network connection)	Android	iPhone
CASIO Apps	Activity App	Trekking	✓	✓	✓	✓	*1	*1	✓	✗
		Fishing	✓	✓	✓	✓	*1	*1	✓	✗
		Cycling	✓	✓	✓	✓	✗	✗	✓	✗
		Snow	✓	✓	✓	✗	✗	✗	✗	✗
		Paddle	✓	✓	✓	✗	✗	✗	✗	✗
		MOMENT SETTER notifications	✓	*2	*2	✓	*2	*2	✓	✗
		LOCATION MEMORY	✓	*2	*2	✗	✗	✗	✗	✗
		Tool	Compass	✓	✓	✓	✓	✓	✓	✓
			Barometer	✓	✓	✓	✓	✓	✓	✓
			Altimeter	✓	✓	✓	✓	✓	✓	✓
			Sunrise / sunset	✓	✓	✓	✓	✓	✓	✗
			Tide Graph	✓	✓	✓	✓	✓	✓	✗
		My Graph	✓	✓	✓	✓	✓	✓	✗	
		MOMENT LINK	✓	✗	✗	✓	✗	✗	✓	✗
		EXILIM Controller	*3	*3	*3	*3	*3	*3	✓	✗
	App assignment to APP button	*4	*4	*4	*4	*4	*4	✓	✓	
Android Wear apps *3	Japan	YAMAP	✓	✓	✓	✓	✗	✗	✓	✗
		なみある?	✓	✗	✗	✓	✗	✗	✓	✗
		GO雨!探知機	✓	✗	✗	✓	✗	✗	✓	✗
	Japan, North America, Germany, Austria, France, Italy, Spain, Hong Kong, Taiwan, Thailand, Russia, Singapore, (India)	ViewRanger	✓	✗	*6	✓	✗	✗	✓	✗
		Hole19	✓	✓	✗	✗	✗	✗	✗	✗
		※Hole19 is not supported in Japan.	✓	✓	✗	✗	✗	✗	✗	✗
		Glassy	✓	✓	✗	✗	✗	✗	✗	✗
	MyRadar	✓	✗	✗	✓	✗	✗	✓	✗	
	※MyRadar is not supported in Spain, Hong Kong, Taiwan, Thailand, Russia, and Singapore.	✓	✗	✗	✓	✗	✗	✓	✗	
Google Apps		✓	Limitation	Limitation	✓	Limitation	Limitation	✓	Limitation	
App Add-on Install		✓	✓	✗	✓	✓	✗	✓	✗	
Watch Faces	CASIO Watch Faces	✓	✓	Limitation	✓	✓	Limitation	✓	Limitation	
	Watch Face Add-ons	✓	✓	✗	✓	✓	✗	✓	Limitation	
Notifications		*5	*5	✗	*5	*5	✗	*5	*5	
Voice Commands		✓	Limitation	✗	✓	Limitation	✗	✓	Limitation	
Other	Gesture Control	✓	✓	✓	✓	✓	✓	✓	✓	

- \*1 Map display not supported.
- \*2 Approaching or moving away from a registered site not supported.
- \*3 Requires app installation.
- \*4 App can be assigned to the APP button using the Android Wear 2.0 setting function.
- \*5 Notification behaviors depend on each Apps; thus, not all Apps would be vibrating.
- \*6 When using WSD-F20/F20S alone paired with Android smartphone

