

内蔵音楽データ一覧・Built-in Music Data Lists・Listas de datos de música incorporados・Listen der vorinstallierten Musikdaten・Listes des données de musique intégrées・Ingebouwde muziekgegevenslijsten・Liste dei dati musicali incorporati・Listor över inbyggda musikdata・Listas dos dados de música incorporados・内置音乐数据列表・内置音樂資料列表・Списки встроенных музыкальных данных・Dahili Müzik Veri Listeleri

音色リスト	Tone List	Lista de tonos	Klangfarbenliste	Liste des sonorités	Toonlijst	Lista dei timbri
① カテゴリー名	Category Name	Nombre de la categoría	Kategoriename	Nom de catégorie	Categoriennaam	Nome di categoria
② 番号	Number	Número	Nummer	Numéro	Nummer	Numero
③ 音色名	Tone Name	Nombre del tono	Klangfarbenname	Nom de sonorité	Toonnaam	Nome di timbro
④ プログラムチェンジ	Program Change	Cambio de programa	Programmwechsel	Changement de programme	Programmaverandering	Cambio di programma
⑤ バンクセレクトMSB	Bank Select MSB	MSB de selección de banco	Bankwahl MSB	MSB sélection de banque	Bankselectie MSB	MSB di selezione banco
⑥ DSPトーン	DSP Tone	Tono DSP	DSP-Klangfarbe	Sonorité DSP	DSP-toon	Timbro DSP

Tonlista	Lista dos sons	音色列表	音色列表	Перечень тембров	Ton Listesi
① Kategorinamn	Nome da categoria	类别名	類別名	Название категории	Kategori Ismi
② Nummer	Número	编号	編號	Номер	Numara
③ Tonnamn	Nome do som	音色名	音色名	Название тембра	Ton Ismi
④ Programändring	Mudança de programa	程序变化	程式變化	Смена программы	Program Değişikligi
⑤ Bankval MSB	MSB de seleção de banco	庫选择MSB	庫選擇MSB	Выбор банка, старший разряд	Bank Seçimi MSB
⑥ DSP-ton	Som DSP	DSP 音色	DSP 音色	ЦОС-тембр	DSP Tonu

①	②	③	④	⑤	⑥
GRAND PIANO					
001	Privia GRAND HG	0	3		
002	Privia GRAND HG BRIGHT	1	1		
003	Privia GRAND HG MELLOW	0	2		
004	Privia GRAND NY	0	17		
005	Privia GRAND NY BRIGHT	0	18		
006	Privia GRAND NY MELLOW	0	19		
007	Privia GRAND BN	0	20		
008	Privia GRAND BN BRIGHT	0	21		
009	Privia GRAND BN MELLOW	0	22		
BEST-HIT PIANOS					
010	IMAGE PIANO	1	20	DSP	
011	CLOCK PIANO	1	21	DSP	
012	LET PIANO	1	22	DSP	
013	YOUR PIANO	1	23	DSP	
014	HUMAN PIANO	1	24	DSP	
015	THOUSAND PIANO	1	25	DSP	
016	PIANO LIKE YOU	1	26	DSP	
017	RHAPSODIC PIANO	1	27	DSP	
018	LADY PIANO	1	28	DSP	
019	V.INSANE PIANO	1	29	DSP	
020	HARD TO PIANO	1	30	DSP	

①	②	③	④	⑤	⑥
VARIOUS PIANOS					
021	STAGE PIANO	0	1	DSP	
022	BALLAD PIANO	0	40	DSP	
023	GRACEFUL PIANO	0	41	DSP	
024	CRISP PIANO	0	42	DSP	
025	FINE UPRIGHT	0	43	DSP	
026	STANDARD UPRIGHT	0	44	DSP	
027	RAGTIME PIANO	3	20	DSP	
028	CONCERT HALL GRAND	0	45	DSP	
029	COOL GRAND	0	46	DSP	
030	DANCE PIANO	1	3	DSP	
031	LA PIANO	1	4		
032	TACK PIANO	0	33	DSP	
033	HONKY-TONK 1	3	32		
034	HONKY-TONK 2	3	34	DSP	
035	OCTAVE PIANO 1	3	33	DSP	
036	OCTAVE PIANO 2	3	35	DSP	
037	STRINGS PIANO	0	34		
038	PIANO PAD	0	35		
039	NEW AGE PIANO	0	38	DSP	

①	②	③	④	⑤	⑥
CLASSIC E.PIANOS 1					
040	TAXI EP	4	54	DSP	
041	FLYING BUTTER EP	4	39	DSP	
042	STILL CRAZY EP	4	52	DSP	
043	NEO SOUL EP	4	43	DSP	
044	JUST THE WAY EP	4	31	DSP	
045	NOT IN LOVE EP	4	51	DSP	
046	STORM RIDER EP	4	50	DSP	
047	NOT LIKE EP	4	42	DSP	
048	JUST LIKE THAT EP	4	30	DSP	
049	SPACE BOY EP	4	29	DSP	
050	WAY OF THE WORLD EP	4	53	DSP	
051	HONEY EP	4	40	DSP	
052	LOVIN' U EP	4	34	DSP	
053	DIAMOND EP	4	38	DSP	
054	MAD SUMMER EP	4	33	DSP	
055	MY BEST EP	4	45	DSP	
056	INDESTRUCTIBLE EP	4	46	DSP	
057	HATHA EP	4	55	DSP	
058	DARK SIDE EP	4	56	DSP	
059	WHERE IT IS EP	4	57	DSP	
060	SWEET TABOO EP	5	22	DSP	
061	GREATEST LOVE EP	5	23	DSP	
062	EU EP	5	25	DSP	
063	FOOTPRINTS EP	5	21	DSP	
064	HARD HABIT EP	5	24	DSP	
065	WHAT A FOOL EGP	2	35	DSP	
066	THE LINE EGP	2	36	DSP	
067	MAGICAL EP	4	41	DSP	
068	NO QTR EP	4	44	DSP	
069	DODODODO EP	4	49	DSP	
CLASSIC E.PIANOS 2					
070	STAGE EP	4	24	DSP	
071	AMP EP	4	26	DSP	
072	PHASER EP	4	15	DSP	
073	CRUNCH EP	4	23	DSP	
074	DYNO EP	4	17	DSP	
075	60'S EP	4	6	DSP	
076	AMP 60'S EP	4	19	DSP	
077	TREM 60'S EP	4	25	DSP	
078	GXYSA EP	5	26	DSP	
079	FMSA EP	5	27	DSP	

①	②	③	④	⑤	⑥
080	SA DETUNE EP	5	28	DSP	
081	LA FANTASIA	5	29	DSP	
082	FM BELL HEAVEN	5	30	DSP	
083	GALAXIA EP	5	16	DSP	
084	90'S EP	4	21	DSP	
085	DIGITAL EP	5	19	DSP	
086	LUCENT EP	5	17	DSP	
087	E.PIANOT	4	47	DSP	
088	RM EP	4	48	DSP	
089	ELEC.GRAND PIANO	2	32	DSP	
CLAVI					
090	SUPER CLAVI	7	24	DSP	
091	AMP CLAVI	7	34	DSP	
092	WAH CLAVI	7	25	DSP	
093	CLAVI	7	1		
HARPSICHORD					
094	HARPSICHORD 1	6	1	DSP	
095	HARPSICHORD 2	6	32		
096	COUPLED HARPSICHORD	6	33	DSP	
097	AMBIENT HARPSICHORD	6	35	DSP	
VIBRAPHONE					
098	VIBRAPHONE	11	24	DSP	
099	VIBRAPHONE WIDE	11	3		
100	MARIMBA	12	32		
101	CELESTA	8	1		
102	GLOCKENSPIEL	9	1		
103	MUSIC BOX	10	32		
ORGAN 1					
104	JS ORGAN	17	32	DSP	
105	RTF FD ORGAN	16	32	DSP	
106	ROCK OD ORGAN	18	32	DSP	
107	TREMOLO ORGAN	16	5	DSP	
108	DP ORGAN	16	4	DSP	
109	JAZZ ORGAN	17	33	DSP	
110	ELEC.ORGAN 1	16	1	DSP	
111	ELEC.ORGAN 2	16	2	DSP	
112	AMP ORGAN	16	24	DSP	
113	ROCK ORGAN 1	18	24	DSP	
114	HARD ROCK ORGAN	18	25	DSP	
115	GOSPEL ORGAN	20	24	DSP	
116	PERC.ORGAN 1	17	1	DSP	
117	VELO.ORGAN	16	25	DSP	

①	②	③	④	⑤	⑥
118	PERC.ORGAN 2	17	39	DSP	
119	FULL DRAWBAR	16	3	DSP	
120	ROCK ORGAN 2	18	2	DSP	
121	F-ORGAN	16	26	DSP	
122	V-ORGAN	16	27	DSP	
123	CLICK ORGAN	17	37	DSP	
124	ROTARY F-ORGAN	16	28	DSP	
125	ROTARY V-ORGAN	16	29	DSP	
ORGAN 2					
126	CHAPEL ORGAN	19	34	DSP	
127	PIPE ORGAN	19	2	DSP	
128	THEATER ORGAN	19	1		
129	PUFF ORGAN	20	33		
130	REED ORGAN	20	25	DSP	
131	ACCORDION FRENCH	21	32	DSP	
132	ACCORDION ITALY	21	1		
STRING ENSEMBLE					
133	STEREO STRINGS	48	32	DSP	
134	MELLOW STRINGS	49	1		
135	BRIGHT STRINGS	49	2		
136	WARM STRINGS	48	5		
137	PIZZICATO STRINGS	45	32		
138	ORCHESTRA HIT	55	32		
139	STRING QUARTET	48	37		
SYNTH PAD					
140	SYNTH-STRINGS 1	50	36		
141	SYNTH-STRINGS 2	50	37		
142	SYNTH-STRINGS 3	50	38	DSP	
143	SYNTH-STRINGS 4	51	32	DSP	
144	DIGITAL SYNTH-STR. 1	51	33	DSP	
145	SUPER SAW PAD	90	6		
146	OLD TAPE PAD	88	5	DSP	
147	FANTASIA	88	33	DSP	
148	XENON PAD	88	32	DSP	
149	70'S SYNTH-STR. 1	50	3		
150	70'S SYNTH-STR. 2	50	32		
151	80'S SYNTH-STR. 1	50	33		
152	80'S SYNTH-STR. 2	50	34		
153	DIGITAL SYNTH-STR. 2	50	4	DSP	
154	FAST SYNTH-STRINGS	50	5		
155	SLOW SYNTH-STRINGS	50	35		
156	NEW AGE	88	2		

①	②	③	④	⑤	⑥
157	WARM PAD	89	1		
158	SPACE PAD	103	1		
159	SOUND TRACK	97	34	DSP	
CHOIR					
160	CHOIR AAHS	52	1		
161	SLOW CHOIR	52	32		
162	VOICE DOO	53	32		
163	VOICE UUH	53	33		
164	VOICE ENSEMBLE	54	2		
165	PROGRESSIVE VOICE	88	4	DSP	
166	VOCODER	54	33	DSP	
167	SYNTH CHOIR	54	34	DSP	
GUITAR					
168	NYLON GUITAR VELO.SLIDE	24	32		
169	STEEL GUITAR VELO.SLIDE	25	32		
170	DYNAMIC NYLON GUITAR	24	24	DSP	
171	DYNAMIC STEEL GUITAR	25	24	DSP	
172	NYLON STR.GUITAR	24	4	DSP	
173	STEEL STR.GUITAR	25	3		
174	12 STR GUITAR	25	5		
175	CRUNCH JAZZ GUITAR	26	3	DSP	
176	CLEAN GUITAR 1	27	2	DSP	
177	CLEAN LEAD GUITAR	27	24	DSP	
178	CRY DIST GUITAR	30	24	DSP	
179	CLEAN GUITAR 2	27	7		
180	MUTE GUITAR	28	1		
181	HUM BLUES GUITAR	29	5	DSP	
182	VINTAGE OD GUITAR	29	37	DSP	

①	②	③	④	⑤	⑥
BASS					
183	ACOUSTIC BASS 1	32	2		
184	ACOUSTIC BASS 2	32	3	DSP	
185	ACOUSTIC BASS 3 (For Music)	32	48		
186	ACOUSTIC BASS 4 (For Music)	32	49	DSP	
187	ACOUSTIC BASS 5	32	1		
188	RIDE BASS	32			

ドラム音色リスト	
①	音名
②	ノートナンバー
③	DRUMS SET NAME
←	STANDARD SET 1と同じ音です。

Drum Assignment List	
①	Key
②	Note No.
③	DRUMS SET NAME
←	indicates a key is assigned the same tones as it is for STANDARD SET 1.

Lista de asignación de batería	
①	Clave
②	Nº de nota
③	DRUMS SET NAME
←	indica que se ha asignado a la tecla el mismo tono que STANDARD SET 1.

Schlagzeug-Sound-Liste	
①	Tonname
②	Noten-Nr.
③	DRUMS SET NAME
←	gibt an, dass einer Taste die gleichen Sounds zugewiesen sind wie für STANDARD SET 1.

Liste des sons de batterie	
①	Note
②	No. de note
③	DRUMS SET NAME
←	indique une touche associée aux mêmes sonorités que pour STANDARD SET 1.

Drumtoewijzingslijst	
①	Toets
②	Nootnr.
③	DRUMS SET NAME
←	geeft aan dat aan een klaviertoets dezelfde tonen toegewezen worden als voor STANDARD SET 1.

Lista di assegnazione batteria	
①	Tasto
②	No. nota
③	DRUMS SET NAME
←	indica che un tasto è assegnato agli stessi timbri come per STANDARD SET 1.

Trumtildelningslista	
①	Tangent
②	Nothr
③	DRUMS SET NAME
←	anger en tangent som är tilldelad samma toner som den är för STANDARD SET 1.

Lista das atribuições de bateria	
①	Tecla
②	Nº da nota
③	DRUMS SET NAME
←	indica que uma tecla está atribuída com os mesmos sons de STANDARD SET 1.

鼓音分配表	
①	音名
②	音符编号
③	DRUMS SET NAME
←	表示琴鍵上分配了与 STANDARD SET 1 相同的音色。

鼓音分配表	
①	音名
②	音符編號
③	DRUMS SET NAME
←	表示鍵盤琴鍵分配了與 STANDARD SET 1 相同的音色。

Таблица соответствия клавишам звуков ударных инструментов	
①	Клавиша
②	Номер ноты
③	DRUMS SET NAME
←	означает тот же звук, что и в стандартном наборе «STANDARD SET 1».

Davul Atama Listesi	
①	Tuş
②	Nota No.
③	DRUMS SET NAME
←	STANDARD SET 1'de olduğu gibi bir tuşun aynı tonlara atandığını belirtir.

		Tone Category: DRUM SET												
		③												
		393: STANDARD SET 1	394: STANDARD SET 2	395: DANCE SET 1	396: DANCE SET 2	397: DANCE SET 3	398: DRUM MACHINE SET	399: JAZZ SET	400: BRUSH SET					
C-1		0	Tabla Ge			Dance1 Kick 1					Dance1 Kick 1			Brush Snare Sweep Ten. 1
D-1	C-1	1	Tabla Ka			Dance1 Kick 2					Dance1 Kick 2			Brush Snare Sweep Ten. 2
F-1	E-1	2	Tabla Te			Dance1 Kick 3					Dance1 Kick 3			Brush Snare Sweep Ten. 3
E-1		3	Tabla Na			Dance1 Kick 4					Dance1 Kick 4			Brush Snare Sweep Ten. 4
E-1		4	Tabla Tun			Dance1 Kick 5					Dance1 Kick 5			Brush Snare Sweep Ten. 5
F-1	F-1	5	Dholak Ge			Dance1 Snare 1					Dance1 Snare 1			Brush Snare Sweep Ten. 6
F-1		6	Dholak Ke			Dance1 Snare 2					Jazz Snare Side Stick SnryOff			Brush Snare Sweep Ten. 7
G-1		7	Dholak Ta 1			Dance1 Snare 3					Jazz Snare Ghost SnryOff			Brush Snare Sweep Short 1
A-1	A-1	8	Dholak Ta 2			Dance1 Snare 4					Jazz Snare Flam SnryOff			Brush Snare Sweep Short 2
A-1		9	Dholak Na			Dance1 Snare 5					Dance1 Snare 5			Brush Snare Sweep Loop 1
B-1	B-1	10	Dholak Ta 3			Dance1 Snare 6					Dance1 Snare 6			Brush Snare Sweep Loop 2
B-1		11	Dholak Ring			Dance1 Snare 7					Jazz Snare Roll Loop			Brush Snare Sweep Loop 2
C0		12	Midangam Tha			Dance1 Snare 8					Dance1 Snare 8			Brush Snare Sweep Long 1
D0	C0	13	Midangam Dhom			Dance1 Snare 9					Jazz Snare Open Rim Shot			Brush Snare Sweep Long 2
D0		14	Midangam Dhi			Dance1 Tambourine					Dance1 Tambourine			
E0	E0	15	Midangam Dhin			Hip-Hop Snare 4					Hip-Hop Snare 4			Brush Snare Sweep 1
F0		16	Midangam Num			Hip-Hop Snare 3					Hip-Hop Snare 3			Brush Snare Sweep 2
F0	F0	17				Techno Snare					Techno Snare			Brush Snare Sweep 3
G0		18				Hip-Hop Rim Shot					Hip-Hop Rim Shot			Brush Snare Sweep 4
A0	A0	20				Hip-Hop Snare 3 Rev.					Hip-Hop Snare 3 Rev.			Brush Snare Sweep 5
A0		21				DM2 Kick 1 Rev.					DM2 Kick 1 Rev.			Brush Snare Sweep Acc. 1
B0	B0	22				Reverse Cymbal Gate					Reverse Cymbal Gate			Brush Snare Sweep Acc. 2
B0		23				Hip-Hop Snare 4 Gate					Dance4 Snare Rev.			Brush Snare Sweep Acc. 3
C1		24				Standard3 Snare 1 mf					Dance4 Open Hi-Hat Rev.			Brush Snare Accent
C1	C-1	25				Techno Snare Gate					Techno Snare Gate			Brush Snare Ghost
D1		26				Hip-Hop Side Stick Gate					Hip-Hop Side Stick Gate			
E1	E-1	27				Hand Clap 2 Gate					Hand Clap 2 Gate			
E1		28	High Q Slap			←					←			Jazz Pedal Open Hi-Hat
F1		29	Scratch Push			←					←			←
F1	F-1	30	Scratch Pull			←					←			←
G1		31	Scratch			←					←			←
A1	A-1	32	Square Click			←					←			←
A1		33	Metronome Click			←					←			←
B1	B-1	34	Metronome Bell			←					←			←
C2		35	Standard1 Kick 2			Standard3 Kick 2					DM2 Kick 2			Jazz Kick 18" Low Mute
C2		36	Standard1 Kick 1			Standard3 Kick 1					DM2 Kick 1			Jazz Kick 18" Low
D2	C-2	37	Standard1 Side Stick			Standard2 Side Stick					Dance4 Hand Clap 1			Jazz Side Stick
D2		38	Standard1 Snare 1			Standard3 Snare 1					DM2 Snare 1			Brush Snare Slap Mute
E2	E-2	39	Hand Clap 1			DM2 Snare 1					DM2 Snare 1			Brush Snare Half Mute
E2		40	Standard1 Snare 2			Standard3 Snare 2					Dance4 Snare 2			Brush Snare Sweep 5
F2		41	Standard1 Low Tom 2			Standard3 Low Tom 2					DM2 Low Tom 2			Brush Low Tom 2
F2	F-2	42	Standard1 Closed Hi-Hat			Standard3 Closed Hi-Hat					DM2 Closed Hi-Hat 1			Brush Closed Hi-Hat
G2		43	Standard1 Low Tom 1			Standard3 Low Tom 1					DM2 Low Tom 1			Brush Low Tom 1
A2	A-2	44	Standard1 Pedal Hi-Hat			Standard3 Pedal Hi-Hat					DM2 Closed Hi-Hat 2			Jazz Pedal Hi-Hat
A2		45	Standard1 Mid Tom 2			Standard3 Mid Tom 2					DM2 Mid Tom 2			Brush Mid Tom 2
B2	B-2	46	Standard1 Open Hi-Hat			Standard3 Open Hi-Hat					DM2 Open Hi-Hat			Brush Open Hi-Hat
B2		47	Standard1 Mid Tom 1			Standard3 Mid Tom 1					DM2 Mid Tom 1			Brush Mid Tom 1
C3		48	Standard1 High Tom 2			Standard3 High Tom 2					DM2 High Tom 2			Brush High Tom 2
C3	C-3	49	Standard1 Crash Cymbal 1			Standard3 Crash Cymbal 1					DM2 High Tom 2			Brush Crash Cymbal
D3		50	Standard1 High Tom 1			Standard3 High Tom 1					DM2 High Tom 1			Brush High Tom 1
D3	E-3	51	Standard1 Ride Cymbal 1			Standard3 Ride Cymbal 1					Standard3 Ride Cymbal 1			Brush Ride Cymbal Tip
E3		52	Standard1 Chinese Cymbal			Standard3 Chinese Cymbal					Standard3 Chinese Cymbal			Brush Chinese Cymbal
F3		53	Standard1 Ride Bell			Standard3 Ride Bell					Standard3 Ride Bell			Brush Ride Bell
G3	F-3	54	Tambourine			←					←			←
G3		55	Standard1 Splash Cymbal			Standard3 Splash Cymbal					Standard3 Splash Cymbal			Jazz Splash Cymbal
A3	A-3	56	Cowbell			←					←			←
A3		57	Standard1 Crash Cymbal 2			Standard3 Crash Cymbal 2					Standard3 Crash Cymbal 2			Jazz Crash Cymbal
B3	B-3	58	VibraSlap			←					←			Brush Ride Cymbal Edge 1
B3		59	Standard1 Ride Cymbal 2			Standard3 Ride Cymbal 2					Standard3 Ride Cymbal 2			Brush Ride Cymbal Edge 2
C4		60	High Bongo			DM1 Kick 2					Dance4 Kick 4			
D4		61	Low Bongo			DM1 Kick 1					DM1 Kick 1			
D4		62	Mute High Conga			DM1 Rim Shot					Dance4 Hand Clap 3			
E4	E-4	63	Open High Conga			DM1 Snare 1					Dance4 Hand Clap 4			
E4		64	Open Low Conga			DM1 Hand Clap					Dance4 Hand Clap 5			
F4		65	High Timbale			DM1 Snare 2					Dance4 Snare 3			
G4	F-4	66	Low Timbale			DM1 Low Tom 2					DM1 Low Tom 2			
G4		67	High Agogo 1			DM1 Closed Hi-Hat 1					Dance4 Closed Hi-Hat 3			
A4	A-4	68	Low Agogo 1			DM1 Low Tom 1					DM1 Low Tom 1			
A4		69	Standard1 Chinese Cymbal			DM1 Closed Hi-Hat 2					Dance4 Closed Hi-Hat 4			
B4	B-4	70	Maracas 1			DM1 Mid Tom 2					Cabasa 2			
B4		71	High Whistle 1			DM1 Open Hi-Hat					Dance4 Open Hi-Hat 2			
C5		72	Low Whistle 1			DM1 Mid Tom 1					DM1 Mid Tom 1			
C5	C-5	73	Short Guro			DM1 High Tom 2					DM1 High Tom 2			
D5		74	Long Guro			DM1 Crash Cymbal					DM1 Crash Cymbal			
E5	E-5	75	Claves 1			DM1 High Tom 1					DM1 High Tom 1			
E5		76	High Wood Block			DM1 Ride Cymbal					DM1 Ride Cymbal			
F5		77	Low Wood Block			Standard3 Chinese Cymbal					Standard3 Chinese Cymbal			
F5	F-5	78	Mute Cuica			Standard3 Ride Bell					Standard3 Ride Bell			
G5		79	Open Cuica			DM1 Tambourine					DM1 Tambourine			
A5	A-5	80	Mute Triangle 1			Standard3 Splash Cymbal					Standard3 Splash Cymbal			
A5		81	Open Triangle 1			DM1 Cowbell					DM1 Cowbell			
B5	B-5	82	Shaker			Standard3 Crash Cymbal 2					Mute Triangle 2			
B5		83	Jingle Bell 1			VibraSlap					Open Triangle 2			
C6		84	Bell Tree			Shaker 2					Shaker 2			
C6	C-6	85	Castanets			DM1 Kick 3					DM1 Kick 3			
D6		86	Mute Surdo			Hip-Hop Kick 3					Hip-Hop Kick 3			
E6	E-6	87	Open Surdo 1			Standard4 Kick 1					Dance6 Kick 1			
F6		88	Applause 1			Standard4 Snare 1					Dance6 Snare 1			
F6	F-6	89	Applause 2			Hand Clap 3					Dance4 Hand Clap 6			
G6		90				Standard4 Snare 2					Dance6 Snare 2			
G6		91				Elec.Low Tom 2					Elec.Low Tom 2			
A6	A-6	92				Hip-Hop Closed Hi-Hat					Dance4 Closed Hi-Hat 5			
B6		93				Elec.Low Tom 1					Elec.Low Tom 1			
B6		94				Hip-Hop Pedal Hi-Hat					Dance4 Closed Hi-Hat 6			
C7		95				Elec.Mid Tom 2					Elec.Mid Tom 2			
C7	C-7	96	Jingle Bell 2			Hip-Hop Open Hi-Hat					Dance4 Open Hi-Hat 3			
D7		97	Open Surdo 2			Elec.Mid Tom 1					Elec.Mid Tom 1			
D7		98	Cabasa 2			Elec.High Tom 2					Elec.High Tom 2			
E7	E-7	99	Maracas 2			Techno Cymbal					Techno Cymbal			
E7		100	Shaker 2			Elec.High Tom 1					Elec.High Tom 1			
F7		101	Mute Triangle 2			Techno Ride					Techno Ride			
G7	F-7	102	Open Triangle 2			Standard3 Low Tom 2					Standard3 Low Tom 2			
G7		103	High Agogo 2			Room Closed Hi-Hat								