Operation Guide 3550

CASIO

ENGLISH

You can also find information about operational procedures at the CASIO website.

https://s.casio.jp/mw/en/3550/



EN-1

About This Manual 6·30

. 10:58

.≙ 50

B

• Button operations are indicated using the letters shown in the illustration.

- the illustration.
 Each section of this manual provides you with the information you need to perform operations in each mode.
 Note that the product illustrations in this manual are intended for reference only, and so the actual product may appear somewhat different than depicted by an illustration. D

Contents

About This Manual	EN-2
Watch Features	EN-5
Configuring Time and Date Settings To configure time and date settings	
Selecting a Mode	EN-8
Alarm	EN-11
To set the alarm time	EN-12
To stop the alarm	EN-13
To enable and disable the Daily Alarm and Hourly Time Signal	EN-13
To test the alarm	EN-13
Stopwatch	EN-14
To measure elapsed time	
	EN-3

EN-2

A

C

Main Indicators	EN-15
Specifications	EN-16

Watch Features

♦ Alarm

Stopwatch

You can also find information about operational procedures at the CASIO website.



https://s.casio.jp/mw/en/3550/

EN-5


EN-4

A

C



To configure time and date settings In the Timekeeping Mode, press © three times. This causes the seconds to flash on the display. 6·30 B 2. Press (A) to move the flashing in the sequence shown below to select a setting.



EN-6

Selecting a Mode

• Press © to change the mode.

* SU: Sunday MO: Monday TU: Tuesday WE: Wednesday TH: Thursday FR: Friday SA: Saturday


3. Use (1) to change the selected setting.

Screen	This setting item:
50	Reset the second to 00 • 30 to 59 seconds: Adds 1 to minutes
10:58	Change the hour or minute • Holding down (i) changes the current selection at high speed
i2	Toggle between 12-hour (12HR) and 24-hour (24HR) timekeeping
20 23 6-30	Change the year, month, day, or day of the week • Holding down (1) changes the current selection at high speed

• The watch returns to the Timekeeping Mode automatically if you do not perform any button operation for one or two minutes in the Time Setting Mode. EN-7

 \bullet After you perform an operation in any mode, pressing O returns to the Timekeeping Mode.

• Press (B) in any mode to illuminate the face of the watch.



FN-8

Operation Guide 3550

Alarm

When the Daily Alarm is turned on, the alarm sounds for 20 seconds at the preset time each day. When the Hourly Time Signal is turned on, the watch beeps every hour on the hour.

The watch returns to the Timekeeping Mode automatically if you do not perform any button operation for one or two minutes in the Alarm Mode.

CASIO

FN-11




You can also find information about operational procedures at the CASIO website.

https://s.casio.jp/mw/en/3550/



EN-10



EN-17