

DST Setting / Module : 5637

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down © for two seconds.



In the Timekeeping Mode, hold down Ⓐ until the city code starts to flash.



Press © once to display the DST setting mode.



Press Ⓓ to toggle ON and OFF .

4.



Press **A** to return to the Timekeeping Mode.

<Timekeeping Mode Screen>

