

DST Setting / Module : 3502

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down **C** for two seconds.



In the Timekeeping Mode, hold down **A** until the seconds start to flash.



Press **C** once.
"Hours" will flash.



Press **D** to change the hour.

4.



Press to return to the Timekeeping Mode.

<Timekeeping Mode Screen>

