

DST Setting / Module : 5146

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



- Day of the week
- Seconds
- Date or Time

To return to the Timekeeping Mode, press © several times.

1.



In the Timekeeping Mode, hold down (A) for about three seconds.

2.



City code will flash in the upper display.

3.



Press © once.

4.



DST setting (ON or OFF) will appear in the lower display.

5. OFF



ON



Press **(D)** to toggle ON and OFF.

6.



Press **(A)** to exit the setting screen.