

DST Setting Module : 5230

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode from any other mode, hold down (C) button for at least four seconds.



In the Timekeeping Mode, hold down (A) button for two seconds until ADJ appears in the right digital dial.



"SET" will start to flash in the left digital dial. The city code and city name will scroll across the right digital dial.

3.



Press (C) button once.
Current DST setting will appear.

4.



Use (D) button to toggle ON, OFF and AUTO.

5.



Press (A) button to return to
the Timekeeping Mode.