


DST Setting / Module : 5338

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, press © several times.

1.




In the Timekeeping Mode, hold down (A) until the seconds start to flash .

2.



Press © to display the DST setting screen.

<DST Setting Screen>



3.



Press **D** to toggle ON and OFF.

4.



Press **A** to return to the Timekeeping Mode.

<Timekeeping Mode Screen>

