

DST Setting Module : 5441

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode from any other mode, hold down (D) button for about two seconds.

1. A black G-Shock watch with a digital display showing 12:00. A pink circle with the letter 'A' is overlaid on the left side of the watch. A red arrow points from the 'A' button to the text 'ADJ' on the right side of the watch. A red box highlights the 'ADJ' text on the upper display.

Hold down (A) button until ADJ appears in the upper display.

2. A black G-Shock watch with a digital display showing 12:00. A pink circle with the letter 'A' is overlaid on the left side of the watch. A red arrow points from the 'A' button to the text 'NYC' on the right side of the watch. A red box highlights the 'NYC' text on the upper display.

When you release the button, City Code will be flashing in the upper display.

3. A black G-Shock watch with a digital display showing 12:00. A pink circle with the letter 'D' is overlaid on the left side of the watch.

Press (D) button once.

4.



DST indicator and OFF/ON.

DST indicator and the DST setting (ON or OFF) will appear in the upper display .

5.



Press (E) button to toggle ON and OFF.

6.



Press (A) button to exit the setting screen.