

DST Setting / Module : 5590

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down Ⓒ for about two seconds.

1.



In the Timekeeping Mode, hold down Ⓐ until city code appears on the display.

2.



Press Ⓒ to display the DST setting mode.

<DST Setting Mode Screen>



3.



Press ⓓ or ⓑ to toggle ON and OFF.

4.



Press ⓐ to return to the Timekeeping Mode.

<Timekeeping Mode Screen>

