

DST Setting / Module : 5611

Firstly, make sure it is in the Timekeeping Mode.

<Timekeeping Mode Screen>



To return to the Timekeeping Mode, hold down ③ for about two seconds.



In the Timekeeping Mode, hold down ① until city code appears on the display.



Press ③ to display the DST setting mode.

<DST Setting Mode Screen>



3.



Press ⓓ or ⓑ to toggle ON and OFF.

4.



Press ⓐ to return to the Timekeeping Mode.

<Timekeeping Mode Screen>

