

# Android, iOS Function Comparison Chart

✓	Supported
✗	Not supported
✓	More functions than Android Wear 1.x

The initial setup of your smart watch requires use with a phone running the Android OS or iOS.  
Wi-Fi environment required for iOS connection.

Item	 Smart Outdoor Watch PRO TREK Smart WSD-F21HR			 Smart Outdoor Watch PRO TREK Smart WSD-F30			 Smart Outdoor Watch PRO TREK Smart WSD-F20/F20S/F20X/ F20SC/F20A			 Smart Outdoor Watch WSD-F10		
	Wear OS by Google			Wear OS by Google			Wear OS by Google			Wear OS by Google		
	Android	iPhone	Supported with Watch Alone (No network connection)	Android	iPhone	Supported with Watch Alone (No network connection)	Android	iPhone	Supported with Watch Alone (No network connection)	Android	iPhone	Supported with Watch Alone (No network connection)
CASIO Apps	Activity App	Running	✓	✓	✓	✗	✗	✗	✗	✗	✗	✗
		Trail Running	✓	✓	✓	✗	✗	✗	✗	✗	✗	✗
		Trekking	✓	✓	✓	✓	✓	✓	✓	✓	*1	*1
		Fishing	✓	✓	✓	✓	✓	✓	✓	✓	*1	*1
		Cycling	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗
		Snow	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗
		Paddle	✓	✓	✓	✓	✓	✓	✓	✓	✗	✗
	MOMENT SETTER notifications	✓	*2	*2	✓	*2	*2	✓	*2	*2	✓	*2
	LOCATION MEMORY	✓	*2	*2	✓	*2	*2	✓	*2	*2	✗	✗
	Tool	Compass	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Barometer	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Altimeter	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Sunrise / sunset	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
		Tide Graph	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	My Graph	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	MOMENT LINK	✓	✗	✗	✓	✗	✗	✓	✗	✗	✓	✗
	EXILIM Controller	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3
	G'z EYE Controller	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3	*3
Customize hardware buttons	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	*4	
Extend Mode	✓	✓	✓	✓	✓	✗	✗	✗	✗	✗	✗	
Timepiece Mode	*6	*6	*6	*6	*6	*6	*6	*6	*6	✓	✓	
Google Apps	✓	Limitation	Limitation	✓	Limitation	Limitation	✓	Limitation	Limitation	✓	Limitation	
App Add-on Install	✓	✓	✗	✓	✓	✗	✓	✓	✗	✓	✓	
Watch Faces	CASIO Watch Faces	✓	✓	Limitation	✓	✓	Limitation	✓	✓	Limitation	✓	✓
	Watch Face Add-ons	✓	✓	✗	✓	✓	✗	✓	✓	✗	✓	✓
Notifications	*5	*5	✗	*5	*5	✗	*5	*5	✗	*5	*5	
Voice Commands	✓	Limitation	✗	✓	Limitation	✗	✓	Limitation	✗	✓	Limitation	
Other	Gesture Control	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	

\*1 Map display not supported.

\*2 Approaching or moving away from a registered site not supported.

\*3 Requires app installation.

\*4 App can be assigned to the buttons using the Wear OS by Google setting function.

\*5 Notification behaviors depend on each Apps; thus, not all Apps would be vibrating.

\*6 Multi Timepiece Mode